

# CS2500 V2

ART.NO. 118044

**EN**

## **USER MANUAL**

ProNordic

## Contents

|        |  |    |
|--------|--|----|
| 1.     | Introduction .....   | 4  |
| 1.1.   | Document description .....   | 4  |
| 1.2.   | Highlighted boxes.....   | 4  |
| 1.3.   | System overview.....   | 5  |
| 1.3.1. | System structure .....   | 5  |
| 1.3.2. | Ventilation unit's switching space.....  | 6  |
| 1.3.3. | Ventilation unit control cabinet .....   | 8  |
| 2.     | Quick guide .....  | 10 |
| 2.1.   | HMI ProPanel .....   | 10 |
| 2.2.   | Settings .....   | 10 |
| 2.2.1. | Introduction.....  | 10 |
| 2.2.2. | Select language .....  | 10 |
| 2.2.3. | Login.....   | 11 |
| 2.2.4. | Set time/time channels .....   | 11 |
| 2.2.5. | Set the calendar and timing program .....  | 11 |
| 2.2.6. | Week schedule .....  | 12 |
| 2.2.7. | Day schedule .....   | 12 |
| 2.2.8. | Calendar (exceptions and stop) .....   | 13 |
| 2.3.   | Adjust setpoints for speeds and temperatures.....                                      | 14 |
| 2.4.   | Service switch.....  | 14 |
| 2.5.   | Extract air regulation.....  | 14 |
| 2.6.   | Changing the flow display units.....   | 14 |
| 2.7.   | Alarm handling.....  | 14 |
| 3.     | Backup and program updates.....  | 15 |
| 3.1.   | Save a configuration.....  | 15 |
| 3.2.   | Load a configuration .....   | 15 |
| 4.     | General functions.....   | 16 |
| 5.     | Configuration.....   | 17 |
| 5.1.   | Configuration 1 .....  | 17 |
| 5.2.   | Overview of inputs and outputs .....   | 19 |
| 6.     | Cooling.....   | 22 |
| 6.1.   | Installation.....  | 22 |
| 6.2.   | Configuration - Cooling control .....  | 22 |
| 6.3.   | To activate the circulation pump (liquid cooling only).....                            | 22 |
| 6.4.   | Blocking for outdoor air temperature .....   | 22 |
| 6.5.   | Cycle times (cooling machine only) .....   | 22 |
| 6.6.   | Cooling limitation as function of fan speed (cooling machine only).....                | 23 |
| 6.7.   | Setting of temperature setpoints .....   | 23 |
| 7.     | Temperature regulation .....   | 23 |
| 7.1.   | Extract cascade .....  | 23 |
| 7.2.   | To adjust limitations to the inflow temperature in the case of cascade regulation..... | 23 |
| 8.     | Summer/Winter compensation.....  | 24 |
| 8.1.   | Adjustment of fan setpoint in case of high/low outdoor air temperatures .....          | 24 |
| 8.2.   | Parameter settings for fan compensation .....  | 24 |
| 8.3.   | Adjustment of temperature setpoint in case of high/low outdoor air temperatures .....  | 24 |
| 8.4.   | Parameter settings for temperature compensation.....                                   | 24 |
| 8.5.   | Settings switch between summer/winter operation.....                                   | 25 |
| 8.6.   | Switch between summer/winter via physical input .....                                  | 25 |
| 8.7.   | Switch between summer/winter via date/outdoor air temperature .....                    | 26 |
| 8.8.   | Free cooling.....  | 26 |
| 8.9.   | Support operation.....   | 27 |
| 8.9.1. | To activate the function .....   | 27 |
| 8.9.2. | To configure the function .....  | 27 |
| 8.10.  | Temperature test for free cooling operation.....                                       | 28 |

|         |   |    |
|---------|---|----|
| 9.      | Fan regulation.....   | 29 |
| 9.1.    | Select method of regulation.....                              | 29 |
| 9.1.1.  | Selection fan regulation method .....                         | 29 |
| 9.1.2.  | Flow regulation .....   | 29 |
| 9.1.3.  | Fixed speed.....  | 29 |
| 9.2.    | Pressure control .....  | 29 |
| 9.2.1.  | Configuration of measurement ranges in pressure sensors ..... | 30 |
| 9.3.    | External setpoint fan.....                                    | 31 |
| 9.4.    | External fan control via digital inputs .....                 | 32 |
| 9.5.    | Fire fan .....  | 32 |
| 9.3.1.  | Parameter settings for Comp.....                              | 32 |
| 9.3.2.  | Parameter settings for Main .....                             | 32 |
| 10.     | Connection of external equipment.....                         | 33 |
| 10.1.   | Fire damper.....  | 33 |
| 10.2.   | Fire/smoke detector .....                                     | 36 |
| 10.3.   | Air quality CO <sub>2</sub> /CO .....                         | 37 |
| 10.4.   | AUX Damper.....   | 38 |
| 10.5.   | AUX operating mode indicator .....                            | 38 |
| 11.     | Internet.....   | 39 |
| 12.     | ModBus TCP/IP & RS485 .....                                   | 40 |
| 13.     | Climatix Scope Light.....                                     | 41 |
| 14.     | Heating/cooling via heat pump .....                           | 43 |
| 14.1.   | Configuration of control system.....                          | 43 |
| 14.2.   | Installation.....   | 45 |
| 15.     | Combi battery .....   | 46 |
| 15.1.   | Installation.....   | 46 |
| 15.2.   | Configuration .....   | 47 |
| 16.     | Programming of ModBus fans .....                              | 48 |
| 17.     | Reset of ModBus fans.....                                     | 50 |
| 18.     | Zero-point calibration of pressure sensors .....              | 50 |
| 19.     | Emergency Stop.....   | 51 |
| 20.     | Electrical battery.....                                       | 52 |
| 21.     | Water battery.....  | 52 |
| 22.     | Test of functions.....  | 53 |
| 23.     | Expansion module SP90.....                                    | 53 |
| 24.     | Additional cooling .....                                      | 54 |
| 25.     | Additional heating.....                                       | 55 |
| 25.1.   | For water heating .....                                       | 55 |
| 25.1.1. | For configuration of water heating.....                       | 55 |
| 25.1.2. | For configuration of circulation pump for water heating.....  | 56 |
| 25.1.3. | For parameter setting of the water heating.....               | 56 |
| 25.2.   | For electrical heating.....                                   | 57 |
| 25.2.1. | For configuration of electric heating .....                   | 57 |
| 25.2.2. | For parameter setting of the additional heating .....         | 58 |
| 26.     | Fire fan.....   | 59 |
| 27.     | External setpoint .....                                       | 60 |
| 27.1.   | For configuration of external setpoint.....                   | 60 |
| 27.2.   | For parameter setting of external setpoint.....               | 60 |
| 28.     | Mixing damper .....   | 61 |
| 28.1.   | For configuration of the heating sequence .....               | 62 |
| 28.2.   | For parameter setting .....                                   | 62 |
| 29.     | Exhaust air sensor.....                                       | 62 |
| 30.     | Efficiency measurement.....                                   | 62 |

## 1. Introduction

### 1.1. Document description

CS2500 V2 was introduced in March 2024. To check which version is installed on the controller:

**Home > Main Menu > Enter PIN (2000) Home > Main Menu > System Settings > Versions > Application Info.**

If the version is V4.18.00 or lower, it is V1.

If the version is V4.20.00 or higher, it is V2.

This document describes the main functions of the CS2500 automatic control and is divided into different sections for different parts of the system. If you only want to make basic settings to start the ventilation unit, there is a special section describing the startup procedure. If you require more detailed information, select the relevant section in the document.



All electrical connections must be made by an expert.

### 1.2. Highlighted boxes

A number of different text boxes are used in the document to draw the user's attention to various things. This may be anything from pure information text to particularly important details to ensure that the system is not used incorrectly. Here is a brief description of the various boxes:



**DANGER!** When a text box is this colour, it means that a life-threatening or serious personal injury may be the consequence of not following the instructions.



**NOTICE!** When a text box is this colour, it means that a poor utilisation ratio or product operating issues may be the consequence of not following the instructions.



**CAUTION!** When a text box is this colour, it means that material damage may be the consequence of not following the instructions.



**INFO!** When a text box is this colour, it means that it contains important information.

*Our products are subject to continuous development and we therefore reserve the right to make changes. We also accept no liability for any printing errors that may occur.*

### 1.3. System overview

#### 1.3.1. System structure

The control system is divided into two subgroups:

1. One part that is located in the ventilation unit's unit's switching space
2. One part that is located in a separate control cabinet on the outside of the ventilation unit

1

**Terminal blocks** for incoming power supply  
Fuse for automatic control and fans (not electric heating coil)

**Modbus extender** - a communication card that connects the ventilation unit's components to the regulator via data communication

**Power supply board** - a circuit board that distributes the power supply to the ventilation unit's components and makes it possible to connect components to a water heating coil

2

**Regulator** - the ventilation unit's general control system

**Terminal board** - a circuit board with terminal blocks for connecting additional components and accessories


**HMI** - the control panel used to communicate with the regulator




ProPanel



ProPTouch




L-model



S-model

### 1.3.2. Ventilation unit's switching space

#### Modbus extender




A communication card that connects the ventilation unit's components to the regulator.

The four dip switches and the rotary switches marked 'FACTORY' are factory-set and must not be changed.

The board's components have the following functions.

| Component | Function  |
|-----------|---|
| P1        | Power supply  |
| P2        | Control signals to electrical afterheater                             |
| P3        | Control signals to rotor and temperature sensor                       |
| P4        | Communication connection  |
| P5        | Communication connection  |
| P6        | Communication connection  |
| P7        | Communication connection  |
| P8        | Control signals to fans   |
| Q1        | Differential pressure monitor for flow measurement on supply air fan  |
| Q2        | Differential pressure monitor for flow measurement on extract air fan |
| FP1       | Differential pressure monitor for supply air filter                   |
| FP2       | Differential pressure monitor for extract air filter                  |

#### Power supply board



This is a circuit board that distributes the power supply to the components of the ventilation unit (not the electric heating coil) and control cabinet. There is also a terminal block for the return water sensor.

The board's components have the following functions.



| Component | Function   |
|-----------|--|
| P1        | Terminal block for power supply  |
| P2        | Terminal block for protective earth (PE)   |
| P3        | Terminal block for accessories   |
| P4        | Supply voltage L1 Out (not in use)   |
| P5        | Power supply to control cabinet  |
| P6        | Control signals to electric heating coil   |
| P7        | Control signals to electric heating coil and return water sensor signal from water heating coil. |
| P8        | Power supply to rotor control  |
| P9        | Power supply to supply air fan   |
| P10       | Power supply to extract air fan  |
| P11       | Power supply to modbus extender  |
| F2        | Fuse for circuit board power supply  |

Terminal block P3 has the following signals:

| Block 3   |             |  |
|-----------|-------------|--|
| Block no. | Function    | Type   |
| 1         | G0          | Signal earth, external accessory                       |
| 2         | 24VAC       | Power supply, external accessory                       |
| 3         | G0          | Power supply, external accessory                       |
| 4         | AO 0-10V    | (EV heating EB1 control signal)<br>Alternative         |
| 5         | G0          | B5 Temp sensor return water WB1 Signal<br>earth        |
| 6         | DI          | (F10 Overheating thermostat EB1 signal)<br>Alternative |
| 7         | AI          | B5 Temp sensor return water WB1 signal                 |
| 8         | N/A         | (Not used)   |
| 9         | N           | Power supply, external accessory                       |
| 10        | NO          | EV2 (Potential-free contact)                           |
| 11        | C           | EV2 (Potential-free contact)                           |
| 12        | L1 Out 230V | Power supply, external accessory. Max 4A.              |
| 13        | N           | Power supply, external accessory                       |
| 14        | L1 Out 230V | Power supply, external accessory. Max 4A.              |

### 1.3.3. Ventilation unit control cabinet


#### Regulator



The ventilation unit's control system. This is where the control panel (HMI) and sensors and other components of the ventilation unit are connected. It is also possible to connect an SD memory card to back up or reload configuration settings and parameters for the regulator.

The controller can be supplemented with a backup battery type BR2032 to expand the memory of alarm history etc. in the event of a power failure.

#### HMI



The ProPanel control panel has an 8-line graphic display and you navigate the menu tree by turning a dial. Selections are confirmed by pressing the same button.




The ProTouch control panel has a graphic TFT touch display and you navigate the menu tree by touching the display.



**INFO!** The ProTouch panel is not mentioned in further detail in this manual. Please see the separate manual for the panel.



**Terminal board**



This is a circuit board that connects the components to the regulator. External components such as dampers are connected to this board via the terminal blocks on the board.

The board's components have the following functions.

| Component | Function  |
|-----------|---|
| P1        | Connection for power supply                         |
| P2        | Data communication                                  |
| P3        | Data communication                                  |
| P4        | Connection for external pressure sensor (accessory) |
| P5        | Connection for external pressure sensor (accessory) |
| P6        | Connection for 24V transformer                      |
| P7        | Data communication                                  |
| P8        | Connection for digital outputs                      |
| P9        | Connection for control signals                      |
| P10       | Terminal block for 230V signals                     |
| P12       | Terminal block for control signals                  |
| P14       | Terminal block for protective earth (PE)            |

Terminal block P10 has the following signals:

| Block 10  |             |   |
|-----------|-------------|---|
| Block no. | Function    | Type                                    |
| 1         | L1 Out 230V | Power supply, external accessory        |
| 2         | N           | Power supply, external accessory        |
| 3         | L 230V      | Power supply Outdoor air damper         |
| 4         | L1 230V     | Outdoor air damper ON/OFF               |
| 5         | N           | Power supply Outdoor air damper         |
| 6         | L230V       | Power supply Exhaust air damper         |
| 7         | L1 230V     | Exhaust air damper ON/OFF               |
| 8         | N           | Power supply Exhaust air damper         |
| 9         | C           | Cooling step 2 (potential-free contact) |
| 10        | NO          | Cooling step 2 (potential-free contact) |
| 11        | N/A         | (Not used)                              |
| 12        | Alarm C     | Buzzer alarm (potential-free contact)   |

| Block 10  |             |   |
|-----------|-------------|---|
| Block no. | Function    | Type  |
| 13        | Alarm NO    | Buzzer alarm (potential-free contact)                   |
| 14        | Cooling C   | Cooling step 1<br>Cooling/Pump (potential-free contact) |
| 15        | Cooling NO  | Cooling step 1<br>Cooling/Pump (potential-free contact) |
| 16        | L1 Out 230V | Power supply, external accessory                        |
| 17        | Heating NO  | EV1 WB1 Pump  |
| 18        | Heating C   | EV1 WB1 Pump  |
| 19        | N           | Power supply, external accessory                        |
| 20        | N/A         | (Not used)  |
|           |             | Max 4A load on the relay outputs                        |


Terminal block P12 has the following signals:

| Block 12  |          |   |
|-----------|----------|---|
| Block no. | Function | Type  |
| 21        | AO 0-10V | Cooling Control signal                        |
| 22        | G0       | Cooling Signal earth                          |
| 23        | DI       | External control 1 Signal                     |
| 24        | G0       | External control 1 Signal earth               |
| 25        | DI       | External control 2 Signal                     |
| 26        | G0       | External control 2 Signal earth               |
| 27        | DI       | Alarm Fire/smoke Signal                       |
| 28        | G0       | External control 3 Signal earth               |
| 29        | AI 0-10V | Air quality Signal                            |
| 30        | G0       | Air quality Signal earth                      |
| 31        | AO 0-10V | Heating WB1 Control signal valve              |
| 32        | 24VAC    | Power supply Fire damper/Alarm Fire/smoke WB1 |
| 33        | G0       | Heating WB1 Signal earth valve                |
| 34        | DI       | External control 3 Signal                     |
| 35        | DI       | Fire damper position reset Signal             |
| 36        | G0       | Signal earth                                  |
| 37        | AO 0-10V | AUX damper Control signal                     |
| 38        | G0       | AUX damper Signal earth                       |
| 39        | DI       | F10 Overheating thermostat EB1 Signal         |
| 40        | G0       | F10 Overheating thermostat EB1 Signal earth   |
| 41        | CE-      | KNX bus                                       |
| 42        | CE +     | KNX bus                                       |
| 43        | AI 0-10V | External setpoint Supply air fan              |
| 44        | AI 0-10V | External setpoint Extract air fan             |

## 2. Quick guide

### 2.1. HMI ProPanel

A central element in the system is the HMI (control panel), where you can adjust settings and take readings. The control panel consists of an 8-line graphic display, indicator lamps and controls for the settings. Here is a short introduction to the control panel showing how to enter the initial settings in the system.



**Info button**  
Press to enter the main menu

- Off = Stop, cool down
- Red lamp = Fire
- Green lamp, steady = Normal operation
- Flashing green = Starting, Night operation test, Nighttime cooling or Night heating/nighttime cooling.
- Orange lamp, steady = Emergency stop, Alarm stop
- Flashing orange lamp = Fire damper exercise, not in service
- Alternating green/orange = Manual control of output or operating mode

**Display**  
Shows information

**Dial**

- Turn anticlockwise/clockwise to go up/down in menus or to change values
- Press the button to enter a menu or change a value
- Hold the button down to go directly to the login menu if the value you want to change
- requires login.

**Alarm button**

- Flashing red = alarm
- Red lamp, steady = alarm acknowledged but remaining

**ESC button**

- Returns to the previous menu page
- Cancels current editing

### 2.2. Settings

#### 2.2.1. Introduction

The first time the system is started, you need to go through some simple steps to ensure that the system will function.

If a heating coil has been installed in the ventilation unit, this must be configured in the control system (see heating coil manual). There is a quick menu for accessing the commonest functions on the control panel, Language, Timing program and Set point settings.

#### 2.2.2. Select language

To change the language on delivery:

**Start page > Quick menu > Commissioning > Language selection**

Select your preferred language.

### 2.2.3. Login

In order to make changes to the system, it is normally necessary to log in. There are four authority levels in the system, and three of them are password protected. The level at which the user is currently logged in is shown by the number of keys in the top left hand corner of the display. The menus show more options or fewer, depending on the level at which you are logged in.

The following key symbols will be used from now on in the manual to describe the login level before the different menus/functions can be made visible and editable. The same key symbols are shown at the top left of the control panel.

#### The following actions are possible at the different levels:

Level 1: No restrictions, no password required.

- Read access to all menus except system parameters, configuration and detail menus.
- Read access to alarm lists and alarm history.

.....

Level 2: End user, password 1000.

One key symbol 

- All rights as for level 1, plus:
- Read access to all menus except configuration menus.
- Write access to the most important setpoints (Setpoints/Settings > Setpoints).
- Alarms and alarm history can be acknowledged and reset.

.....


Level 3: System administrator, password 2000.

Two key symbol 

- All rights as for level 2, plus:
- Rights to all menus except I/O configuration and system settings.

.....

Level 4: OEM, password given only in consultation with the Flexit service organisation.

Three key symbol 


- All rights as for level 3, plus:
- Rights to all menus and system settings.

**Start page > Main menu > Enter PIN**

### 2.2.4. Set time/time channels

 **Start page > Quick menu > SetUp > Date/Time Input**

### 2.2.5. Set the calendar and timing program

 **Start page > Quick menu > SetUp > Timeswitch program**

#### General

This section describes functions and settings for the timing program and calendars.

When no object with higher priority (for example Manual control <> Auto) is activated, the system can be switched off or the steps changed via the timing program. A maximum of six switch-over times can be specified per day.

The calendar stop overrides the calendar exception, which in turn overrides the normal timing program (only in operating mode). Up to 10 periods or exception days can be specified for each calendar.



**NB.** Both setpoints for fan steps and temperature setpoints (comfort /economy) are controlled by the timing program.

### 2.2.6. Week schedule

| Parameter     | Value  | Function  |
|---------------|--|---|
| Present value | ---  | Switch-over according to schedule   |
| Monday        |  | Shows current command when the current day is Monday. The latest time that can be entered for a day is 23:59. Go to the daily switch-over schedule for Mondays.             |
| Copy schedule | -Mo<br>-Tu-Fr<br>-Tu-Su<br>-Tu<br>-We<br>-Th<br>-Fr<br>-Sa<br>-Su<br>-Ecpt | Copies times for the timing program from Monday to Tuesday-Friday/Tuesday-Sunday.<br>-Passive (no copying).<br>-Copying starts. Return to the display screen.<br>-Exception |
| Tuesday       |  | Same function as for Monday.  |
| ...           |  | ...   |
| Sunday        |  | Same function as for Monday.  |
| Exception     |  | Shows current command when the current day is an exception day. Go to the daily switch-over schedule for exception days.  |
| Period: Start |  | (Only Authority level 3.)<br>Start date for weekly schedule. *,**. 00 means that the weekly schedule is always activated. ---> Activate weekly schedule.                    |
| Period: End   |  | (Only Authority level 3.)<br>Start date and time for disabling of weekly schedule.  |

### 2.2.7. Day schedule

| Parameter              | Value  | Function  |
|------------------------|--|---|
| Present value          | ---  | Switch-over according to the schedule when the current weekday is the same as the switch-over day   |
| Day schedule           | -Passive<br>-Active  | Status for current week or exception day:<br>-Current weekday (system day) is not the same as the switch-over day.<br>-Current weekday (system day) is the same as the switch-over day. |
| Time-1                 |  | This is locked to 00:00   |
| Value-1                | Off<br>Eco.St1<br>Comf.St1<br>Eco.St2<br>Comf.St2<br>Eco.St3<br>Comf.St3 | Indicates the unit's operating mode when Time-1 occurs  |
| Time-2                 | 00:01-23:59  | Switch-over time 2.<br>*:* ---> Time inactivated  |
| Value-2 ...<br>Value-6 | Off<br>Eco.St1<br>Comf.St1<br>Eco.St2<br>Comf.St2<br>Eco.St3<br>Comf.St3 | Indicates the unit's operating mode when Time-2 occurs  |
| Time-3<br>Time-6       | 00:01-23:59  | Switch-over time 3-6.<br>*:* ---> Time deactivated  |

### 2.2.8. Calendar (exceptions and stop)

Exception days can be defined in the calendar. These can include specific days, periods or weekdays. Exception days override the weekly schedule.

#### Calendar exceptions

Switch-over follows the weekly schedule and the exceptions specified in the daily schedule when a switch-over time is activated in the calendar exception.

#### Calendar stop

The system is turned off when the calendar stop is activated.

#### Parameter:

**Start page > Quick menu > SetUp > Timeswitch program > Calendar exception**

**Start page > Quick menu > SetUp > Timeswitch program > Calendar fix off**

| Parameter     | Value                                      | Function   |
|---------------|--|--|
| Current value | -Passive<br>-Active                        | Shows whether a calendar time is activated:<br>- No calendar time activated<br>- Calendar time activated   |
| Selection -x  | -Date<br>-Interval<br>-Weekday<br>-Passive | Specification of exception type:<br>-A certain day (e.g. 1 May)<br>-A period (e.g. holiday)<br>-A certain weekday<br>-Times are deactivated<br>This value must always be placed last, after the date |
| -(Start) Date |  | -Selection-x = interval: Enter the start date for the period<br>-(Selection-x = Date: Enter specific date)   |
| -End date     |  | -Selection-x = interval: Enter the end date for the period<br>The end date must be later than the start date   |
| Weekday       |  | -Selection-x = only weekdays: Enter a weekday.   |

#### Example: Selection-x = Date

Only the time for (start) is relevant.

- (Start)Date = \*,01.01.16  
Result: 1 January 2016 is an exception date.
- (Start)Date = Mo,\*,\*.00  
Every Monday is an exception day
- (Start)Date = \*,\*.Even.00

All days in even months (February, April, June, August, etc.) are exception days.

#### Example: Selection-1 = interval

The times for (Start)Date and End date are adjusted.

- (Start)Date = \*,23.06.16 / -End date = \*,12.07.16.  
23 June 2016 until end of 12 July 2016 are exception days (for example holidays).
- (Start)Date = \*,23.12.16 / End date = \*,31.12.16  
23-31 December are exception days every year. Time End date = \*,01.01.16 will not work, because 1 January comes before 23 December.
- (Start)Date = \*,23.12.16 / -End date = \*,01.01.17.  
23 December 2016 up to and including 1 January 2017 are exception days.
- (Start)Date = \*,\*,\*.17 / -End date = \*,\*,\*.17

**Warning!** This means that the exception is always active! The system is constantly in exception mode or turned off.

#### Example: Selection-1 = Weekday

Selection-1 = Weekday

The times for weekdays are adjusted.

- Weekday = \*,Fr,\*  
Every Friday is an exception day.
- Weekday = \*,Fr,Even  
Every Friday in even months (February, April, June, August, etc.) is an exception day.
- Weekday = \*,\*,\*

**Warning!** This means that the exception is always active! The system is constantly in exception mode or turned off.

### 2.3. Adjust setpoints for speeds and temperatures

 **Start page > Quick menu > Settings > Setpoints/Settings**

| Parameter          | Function   |
|--------------------|--|
| All settings       | >  |
| Comfort htg stpt   | Indicates the temperature setpoint for comfort operation (daily operation)   |
| Economy htg stpt   | Indicates the temperature setpoint for economy operation (nighttime setback) |
| Sply fan st 1 stpt | Indicates the supply airflow step 1  |
| Sply fan st 2 stpt | Indicates the supply airflow step 2  |
| Sply fan st 3 stpt | Indicates the supply airflow step 3  |
| Sply fan st 4 stpt | Indicates the supply airflow step 4  |
| Sply fan st 5 stpt | Indicates the supply airflow step 5  |
| Extr fan st 1 stpt | Indicates the extract airflow step 1   |
| Extr fan st 2 stpt | Indicates the extract airflow step 2   |
| Extr fan st 3 stpt | Indicates the extract airflow step 3   |
| Extr fan st 4 stpt | Indicates the extract airflow step 4   |
| Extr fan st 5 stpt | Indicates the extract airflow step 5   |

### 2.4. Service switch

The service switch is used to stop the unit for servicing. **NB.** If the electric coil was active when the unit was turned off, there will be 180 seconds run-on time before the unit stops cooling the coil.

 **Start page > SERVICE SWITCH**

| Parameter | Function                                |
|-----------|---|
| Auto      | The unit is controlled via time channel |
| Off       | Service mode, the unit is stationary    |

### 2.5. Extract air regulation

As standard, the unit is configured to regulate the temperature via the supply air, but can easily be configured to regulate this via the extract air instead. To do this, go into the following menu:

 **Start page > Main menu > Configuration > Configuration 1 > Tmp control mode**

| Parameter | Function   |
|-----------|--|
| Supply    | Temperature regulation is controlled by the supply air temperature   |
| ExtrSplyC | Temperature regulation is controlled as a function of the extract and supply air sensors and maintains the set extract air temperature |

After making a change in a configuration menu, RESTART.



**Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**



**RESTART**

To adjust limitations to the inlet temperature in the case of extract air regulation.



**Start page > Quick menu > Settings > Setpoints/Settings**

| Parameter      | Function  |
|----------------|---|
| Supply tmp min | Indicates the lowest permitted supply air temperature   |
| Supply tmp max | Indicates the highest permitted supply air temperature, |

### 2.6. Changing the flow display units

The standard setting for the unit is m<sup>3</sup>/h, but can easily be changed to l/s. When the units are changed, the setpoint values for airflow are automatically recalculated.



**Start page > Main menu > Configuration > Configuration 2 > Flow display**

| Parameter         | Function                               |
|-------------------|--|
| No                | Not used                               |
| l/s               | Shows the airflow in l/s               |
| m <sup>3</sup> /h | Shows the airflow in m <sup>3</sup> /h |

After making a change in a configuration menu, RESTART.



**Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute**



**RESTART**

### 2.7. Alarm handling

If an alarm has been triggered, it will be shown by the flashing alarm symbol. You can get more information by pressing the alarm button. To reset the alarm, press the alarm button twice and select 'Confirm/Reset' and then Execute in the menu.

### 3. Backup and program updates


When the system has been fully configured and the parameters have been set, it can be backed up to an SD memory card and/or internally in the regulator, or reset using the data on the memory card or the settings on the regulator. Two different sets of parameters for a configured system can be backed up or reset. For example, you can back up the standard settings (Save factory settings) and adjusted/startup settings (Save startup settings).

The options below can be selected only with the relevant authority level. This is done using menu option:

 **Start page > Main menu > System objects > Save/Load**

#### 3.1. Save a configuration

After initiation and adjustment, the parameters and configurations can be saved to the SD card. For example, you can load these values on another process unit with the same basic configuration (operating system, application, control panel, HMI4Web and language/communication).



*Location of SD memory card*

**Procedure:**

1. Insert a blank SD memory card into the regulator.
2. Backup the values to the memory card.

 **Start page > Main menu > System objects > Save/load > Sett.save > Ext.m. > Execute**

or internally in the controller

 **Start page > Main menu > System objects > Save/load > Sett.service save**

3. Wait until:

 **Start page > Main menu > System objects > Save/load > Ready**

Standard settings (Factory settings) and adjusted settings (Startup settings) are handled in the same way.

#### 3.2. Load a configuration

**Procedure:**


1. Insert the memory card into the regulator.
2. Load the values from the memory card.

 **Start page > Main menu > System objects > Save/Load > Sett.load > Ext. m > Execute**

or internally in the controller

 **Start page > Main menu > System objects > Save/Load > Sett.service load**

3. Wait until:

 **Start page > Main menu > System objects > Save/Load > Ready**

4. Restart the process unit:

 **Start page > Main menu > System objects > Save/Load > Restart required! = Execute**



Standard settings (Factory settings) and adjusted settings (Startup settings) are handled in the same way.

## 4. General functions

### Operating modes - Changes

The system can be set into different operating modes.



**Start page > Main Menu > Unit >  
Operating mode > Manual operation**

| Manual operation |  |
|------------------|--|
| No               | Unit operating on time switch program                    |
| Eco.St1          | Unit operating on economy temperature and "Step 1" speed |
| Comf.St1         | Unit operating on comfort temperature and "Step 1" speed |
| Eco.St2          | Unit operating on economy temperature and "Step 2" speed |
| Comf.St2         | Unit operating on comfort temperature and "Step 2" speed |
| Eco.St3          | Unit operating on economy temperature and "Step 3" speed |
| Comf.St3         | Unit operating on comfort temperature and "Step 3" speed |
| Eco.St4          | Unit operating on economy temperature and "Step 4" speed |
| Comf.St4         | Unit operating on comfort temperature and "Step 4" speed |
| Eco.St5          | Unit operating on economy temperature and "Step 5" speed |
| Comf.St5         | Unit operating on comfort temperature and "Step 5" speed |



## 5. Configuration

On delivery, the ventilation unit is configured and ready. Therefore, no adjustments to the configuration are normally required. If, on the other hand, you have bought a heating battery or other accessory, this must be configured. See the manual for the current accessory.

However, the addition of accessories and other equipment may require a change to the configuration. Where necessary, there is a more detailed description in this manual or with the accessory. This section is, therefore, intended more as general information.

The configuration includes the following three steps:

- Configuration 1
- Configuration 2
- Configuration with inputs and outputs



**NB.** The ventilation unit is supplied fully configured and does not normally need to be changed.

### 5.1. Configuration 1

If adjustments are needed, 'Configuration 1' is the first step in the configuration.

- Configuration is done sequentially, which means that it is not possible to skip any options.
- Configuration 1 must have been completed and the process unit have been restarted before you continue with Configuration 2.
- 



**Start page > Main menu > Configuration > Configuration 1**

After making a change in a configuration menu, RESTART



**Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**



**RESTART**

If adjustments should be needed, the sub-configuration for certain parts of the system can be adjusted in "Configuration 2".

### Prerequisites

- Configuration 1 must be performed, including restarting the regulator.
- Configuration is done sequentially, meaning that no options can be skipped.
- Configuration 2 must have been completed, including restarting the process unit before proceeding with Config. In-Outputs.



**Start page > Main menu > Configuration > Configuration 2**

After making a change in a configuration menu, RESTART



**Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute**



**RESTART**

## 1.1. Configuration of inputs and outputs

If adjustments are needed, sub-functions for certain parts of the system can be configured in Configuration 1, Configuration 2, and Configuration of inputs and outputs.

In Konfig.Inn-og utganger (Configuration of inputs and outputs), a physical location is assigned to the inputs and outputs specified in Configuration 1 and Configuration 2. Additionally, parameter settings are made for the current sensor conversion (for example, Ni1000, Pt1000, 0-10V = 1000 Pa).

### Positions in the controller and expansion modules

- **Controller:** All single-digit positions, for example, X1, DO1.
- **Modbus extender:** All inputs and outputs must be set to Com.
- **Expansion module 1:** All positions start with 1, for example, 1X1x, 1D01.
- **Expansion module 2:** All positions start with 2, for example, 2X1x, 2D01.

### Prerequisites

Configuration 1 must be completed, including restarting the controller.

- Configuration is done sequentially. This means that it is not possible to skip any options.
- Configuration 2 must be completed, including restarting the process unit, before continuing with Config. inputs-outputs.

Then:



**Start page > Main menu > Configuration > Config. Inputs and outputs**



**NB.** The ventilation unit is supplied fully configured and does not normally need to be changed.



**NB.** The inputs and outputs of the expansion modules can be used if the modules have been activated in Configuration 1.

## 5.2. Overview of inputs and outputs

If adjustments are needed, sub-functions for certain parts of the system can be configured in Configuration 1, Configuration 2, and Configuration of inputs and outputs.

### IO type

- DI = Digital input
- AI = Analog input
- DO = Digital output
- AO = Analog output

### Siemens I/O pos

Siemens address of the input/output in the automation system.

### Address in the controller

The address that the physical input/output has in the controller A1 and SP90 module.


### Terminal of the controller (A)

Physical marking on the input/output of the controller A1 and SP90 module


### Terminal of the unit (B)

Physical marking on the inputs/outputs on the circuit board A2, A3, A4 in the unit.


*Regulator*




*SP90 module*



*A2 circuit board*



*A3 circuit board*



| I/O Type | Siemens I/O | Adress in Controller | Connector in Controller | Connector in Unit | Function                                | Comment  |
|----------|-------------|----------------------|-------------------------|-------------------|---|--|
| DI       | 81          | X9                   | T1-X9                   | P12-23            | Extern regulation 1                     | Speed 1 or Speed 3 in combination with DI3. Switch or timer. |
| DI       | 72          | D3                   | T5-DU1                  | P12-27            | Alarm fire/smoke                        | 24V Ref  |
| DI       | 82          | D2                   | T4-D2                   | P12-25            | Extern regulation 2                     | Speed 2 or Speed 3 in combination with DI1. Switch or timer. |
| DI       | 90          | D1                   | T4-D1                   | P12-34            | Extern regulation 3                     | Speed 0. Switch or timer.                                    |
| DI       | 75          | D4                   | T5-DU2                  | P12-35            | Feedback fire damper                    | 24V Ref  |
| DI       | 65          | Com                  | A4 Card                 | -                 | Alarm Supplyfan                         | SPARE Modbus card  |
| DI       | 67          | Com                  | A4 Card                 | -                 | Alarm Extractfan                        | SPARE Modbus card  |
| DI       | 48          | Com                  | A4 Card                 | -                 | Alarm Heat rec.                         | Modbus card  |
| Di       | 44          | Com                  | A4 Card                 | -                 | Alarm electrical heater/ Thermostat F10 | P2-3 on A3 card  |
| AI       | 1           | X10                  | T1-X10                  | -                 | Temperature supply                      | Supply air sensor B1   |
| AI       | 4           | X11                  | T1-X11                  | -                 | Temperature extract                     | Extract air sensor B3  |
| AI       | 5           | X3                   | T2-X3                   | -                 | Temperature outdoor                     | Outdoor sensor B4  |
| AI       | 6           | X6                   | A4 Card                 | P3-7              | Temperatur frost protec.                | Return water sensor B5                                       |
| AI       | 21          | X7                   | T3-X7                   | P4-2 /P12-43      | Pressure supply                         | External pressure sensor supply                              |
| AI       | 22          | X8                   | T3-X8                   | P5-2 / P12-44     | Pressure extract                        | External pressure sensor extract                             |
| AI       | 35          | X4                   | T2-X4                   | P12-29            | Air quality                             | External sensor (CO <sub>2</sub> / CO)                       |
| AI       | 23          | Com                  | A4 Card                 | Q1                | Air flow Supply                         | Pressure sensor supply fan A4-card                           |
| AI       | 24          | Com                  | A4 Card                 | Q2                | Air flow Extract                        | Pressure sensor extract fan A4-card                          |
| AI       | 70          | Com                  | A4 Card                 | PP1               | Filter pressure supply                  | Pressure sensor supply filter A4-card                        |
| AI       | 71          | Com                  | A4 Card                 | PP2               | Filter pressure extract                 | Pressure sensor extract filter A4-card                       |
| AI       | 7           |                      |                         |                   | Temperature Ice Guard                   | Temp. sensor counter flow, not in use                        |
| AI       | 109         |                      |                         |                   | Temperature after heat recover          | Temp. sensor temperature efficiency, not in use              |

| I/O Type | Siemens I/O | Adress in Controller | Connector in Controller | Connector in Unit | Function                         | Comment   |
|----------|-------------|----------------------|-------------------------|-------------------|----------------------------------|---|
| DO       | 131         | Q5                   | T11-Q54                 | P10-4             | Outdoor air damper               |   |
| DO       | 132         | Q6                   | T11-Q64                 | P10-7             | Exhaust air damper               |   |
| DO       | 145/147     | Q3                   | T10-Q33/34              | P10-17/18         | Electric. heater / Water-pump    | 145 = Electric. heater step 1<br>147 = Water pump     |
| DO       | 149/150     | Q4                   | T10-Q43/44              | P10-14/15         | Cooling pump / Cooling machine 1 | 149 = Cooling pump<br>150 = Cooling machine 1         |
| DO       | 168         | Q1                   | T9-Q11/14               | P10-12/13         | Alarm/Operating status output    | AUX Operating status                                  |
| DO       | 133/151     | Q2                   | T10-Q21/24              | P10-9/10          | Fire damper / Cooling machine 2  | 133 = Fire damper<br>151 = Cooling machine 2          |
| DO       | 153         | Com                  | A4 Card                 | P2-4              | Electric. heater step 2          | On/Off signal   |
| AO       | 111         | X1                   | T2-X1                   | P12-37            | AUX damper output                | Damper regulation % depending on selected speed 0-10V |
| AO       | 99          | X2                   | T2-X2                   | P12-21            | Cooling                          | 0-10V   |
| AO       | 96          | X5                   | T2-X5                   | P12-31            | Heating valve                    | 0-10V   |
| AO       | 91          | Com                  | A4 Card                 | -                 | Supply fan 0-10V                 | Spare   |
| AO       | 92          | Com                  | A4 Card                 | -                 | Extract fan 0-10V                | Spare   |
| AO       | 98          | Com                  | A4 Card                 | P3-1              | Heat recovery                    | 0-10V   |


## 6. Cooling

The settings below only apply to a cooling machine. If you want both heating and cooling via a heat pump, see "chap. 14. Heating/cooling via heat pump".

### Cooling via cooling machine or liquid

As standard, the system is set up to control liquid cooling or two cooling machines. Either linear (two cooling machines of equal size) or binary (one small and one large cooling machine). Cooling control in accordance with following guidance.

### 6.1. Installation



### 6.2. Configuration - Cooling control

Then go in via the control panel to configure the system For cooling machine control or liquid.

**Start page > Main menu > Configuration > Configuration 1 > Cooling**

| Parameter             | Function  |
|-----------------------|---|
| Water                 | Analogue output for liquid cooling                                |
| Cooling machine 1step | One analogue and one digital output for cooling machine           |
| Cooling machine 2step | One analogue and two digital outputs for cooling machine          |
| Cooling machine 3step | One analogue and two digital outputs (Binary) for cooling machine |

Enter the desired choice and complete with Ready. After making a change in a configuration menu, RESTART.

**Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**



### 6.3. To activate the circulation pump (liquid cooling only)

**Start page > Main menu > Configuration > Configuration 2 > Cooling pump**

| Parameter | Function                                   |
|-----------|--|
| No        | Pump control deactivated                   |
| Yes       | Pump control activated                     |
| Yes+Kick  | Pump control activated + exercise function |

To make parameter settings, go to the following menus via the control panel.

### 6.4. Blocking for outdoor air temperature

**Start page > Main menu > Unit > Temp control > Cooling > Disable by outs tmp**

| Parameter     | Function   |
|---------------|--|
| -64.0 to 64.0 | Indicates lowest permissible outdoor air temperature for cooling operation |

### 6.5. Cycle times (cooling machine only)

**Start page > Main menu > Unit > Temperature regulation > Cooling > Direct expansion**

| Parameter                | Function                                   | Beskrivning   |
|--------------------------|--|---|
| Operation                | Auto<br>From<br>Step 1<br>Step 2<br>Step 3 | Manual operation of output  |
| Min cycle time           | 0-36000                                    | Minimum initiation time in seconds for cooling machine  |
| Minimum termination time | 5-600                                      | Minimum termination time in seconds for cooling machine   |
| Min step time            | 5-600                                      | Min operating time per step before next step can start  |
| Start step 1             | 0-100%                                     | Percentage cooling load on the regulator when the different steps kick in                       |
| Start step 2             | Start step 1 -100%                         | Percentage cooling force on the regulator when the different steps kick in                      |
| Start step 3             | Start step 2 -100%                         | Percentage cooling load on the regulator when the different steps kick in                       |
| Hysteresis, termination  | 0-20%                                      | How far below the initiation level the step will terminate as the cooling requirement goes down |

## 6.6. Cooling limitation as function of fan speed (cooling machine only)



**Start page > Main menu > Unit > Temperature regulation > Cooling > Max. signal fan step**

| Parameter          | Function  |
|--------------------|---|
| Fan step 1> 0-100% | Permitted cooling machine output signal when the system is running in step 1 or using the setpoint for step 1 |
| Fan step 2> 0-100% | Permitted cooling machine output signal when the system is running in step 2 or using the setpoint for step 2 |
| Fan step 3> 0-100% | Permitted cooling machine output signal when the system is running in step 3 or using the setpoint for step 3 |

### > EXAMPLE OF COOLING LIMITATION

|                   |  |
|-------------------|--|
| Fan step 1 = 30%  | The control system limits the cooling load to 30% at fan step 1. |
| Fan step 2 = 60%  | The control system limits the cooling load to 60% at fan step 2. |
| Fan step 3 = 100% | No limitation of cooling load at fan step 3.                     |

## 6.7. Setting of temperature setpoints



**Start page > Quick menu > Setup > Setpoints/Settings**

| Parameter        | Function   |
|------------------|--|
| Comfort clg stpt | Indicates the temperature setpoint for comfort operation |
| Economy clg stpt | Indicates the temperature setpoint for economy operation |

## 7. Temperature regulation

### 7.1. Extract cascade

As standard, the unit is configured to regulate the temperature via the supply air, but can be reconfigured to regulate this via the extract air. (**Extract air casc**). To do this, go into the following menu.



**Start page > Main menu > Configuration > Configuration 1 > Tmp control mode**

| Parameter | Function  |
|-----------|---|
| Supply    | Temperature regulation of supply air only   |
| Rm casc   | Temperature regulation is controlled by the extract air temperature.  |
| ExtrSplyC | Cascade regulation of room and supply air temperature   |
| RmSplyCSu | Cascade regulation of extract and supply air temperature  |
| ExSplyCSu | Cascade regulation of extract and supply air temperature in summer; regulation of supply air temperature only in winter |
| Room      | Room regulation only.   |
| Extract   | Temperature regulation of extract air only  |

After making a change in a configuration menu, RESTART.



**Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**



### 7.2. To adjust limitations to the inflow temperature in the case of cascade regulation



**Start page > Quick menu > Setup > Setpoints/Settings**

| Parameter      | Function   |
|----------------|--|
| Supply tmp min | Indicates minimum permitted inflow temperature in supply air |
| Supply tmp max | Indicates maximum permitted inflow temperature in supply air |

## 8. Summer/Winter compensation

### Summer compensation:

Adjusts the fan/temperature setpoint in relation to regulation of high outdoor air temperatures in summer. E.g. Lowers temperature setpoint and increases fan setpoint.

### Winter compensation:

Adjusts the fan/temperature setpoint in relation to regulation of low outdoor air temperatures in winter. E.g. Increases the temperature setpoint and lowers the fan setpoint.

### 8.1. Adjustment of fan setpoint in case of high/low outdoor air temperatures



Start page > Main menu > Configuration > Configuration 2 > Fan comp outs tmp

| Parameter | Function             |
|-----------|----------------------|
| No        | Function deactivated |
| Yes       | Function activated   |

After making a change in a configuration menu, RESTART.

Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute



### 8.2. Parameter settings for fan compensation

Start page > Main menu > Unit > Fan control > Act summer comp fan / Act winter comp fan

| Parameter          | Function   |
|--------------------|--|
| Outs air tmp start | Outdoor air temperature when compensation is activated   |
| Outs air tmp end   | Outdoor air temperature when the max (summer) or min (winter) fan setpoint is achieved   |
| Delta              | Setpoint change in %<br>E.g. in airflow regulation and summer compensation:<br>Fan setpoint start = 500 l/s<br>Outdoor air temp start = 20 degrees<br>Outdoor air temp end = 30 degrees<br>Delta = 20%<br>Fan setpoint end (at 30 degrees) = 600 l/s |

### 8.3. Adjustment of temperature setpoint in case of high/low outdoor air temperatures



Start page > Main menu > Configuration > Configuration 2 > Su/Wi comp tmp

| Parameter | Function             |
|-----------|----------------------|
| No        | Function deactivated |
| Yes       | Function activated   |

After making a change in a configuration menu, RESTART.

Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute



### 8.4. Parameter settings for temperature compensation



Start page > Main menu > Unit > Main setpoint > All settings > Settings tmp ctrl > Tmp setpoints > Act summer comp tmp > Act winter comp tmp

| Parameter          | Function   |
|--------------------|--|
| Outs air tmp start | Outdoor temperature when compensation is activated   |
| Outs air tmp end   | Outdoor air temperature when the max (summer) or min (winter) Fan setpoint is achieved   |
| Delta              | Setpoint change in degrees.<br>E.g. in case of temperature regulation and summer compensation:<br>Temperature setpoint start (at 20 degrees) = 22 degrees<br>Outdoor air temp start = 20 degrees<br>Outdoor air temp end = 30 degrees<br>Delta = -5 degrees<br>Temperature setpoint end (at 30 degrees) = 17 degrees |



### 8.5. Settings switch between summer/ winter operation

Switches between extract air regulation in summer and supply air regulation in winter. The function can be switched via three different factors, physical input, date or outdoor air temperature



**Start page > Main menu > Configuration > Configuration 1 > Tmp control mode**

| Parameter | Function  |
|-----------|---|
| ExSplyCSu | Extract air regulation in summer and supply air in winter   |
| RmSplyCSu | Room regulation in summer and supply air in winter. <b>NB.</b> Requires room sensor as external accessory |

### 8.6. Switch between summer/winter via physical input



**Start page > Main menu > Configuration > Configuration 1 > Su/Wi input**

| Parameter | Function  |
|-----------|---|
| No        | Function deactivated  |
| Yes       | Switches between summer/winter operation. 1 = summer & 0 = winter |

After making a change in a configuration menu, RESTART.




**Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**



A physical input must then be connected to the function. There are different inputs to choose between, fire damper reset (fire damper is installed) and external speed control. If fire damper reset is activated, the speed control input is used, and vice versa.



**Start page > Main menu > Configuration > Configuration IOs > Digital inputs > Su/ Wi input**



| Parameter | Function  |
|-----------|---|
| D1        | Used in case of fire damper reset                   |
| D4        | Used if you have speed 3 via external speed control |

If D1 Is selected, the external speed control function must be deactivated. This is done via the following search path.



**Start page > Main menu > Configuration > Configuration 1 > Ext control input > Two**

Ater making a change in a configuration menu, RESTART.



**Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**



### 8.7. Switch between summer/winter via date/outdoor air temperature



**Start page > Main menu > Global functions > State**

| Parameter           |          | Function  |
|---------------------|----------|---|
| Status              |          | Display of current operating status   |
| SuWi setting        | None     | No limitations  |
|                     | NoHeatSu | No heating in summer state  |
|                     | NoCoolWi | No cooling in winter state  |
|                     | Both     | No heating in summer state and no cooling in winter state   |
| Outs air tmp damped |          | Average outdoor air temperature over given time constant  |
| Summer date time    |          | Date/time for switching to summer operation. If * is indicated instead of date/time, the switch is to Outdoor air temp. moderated   |
| Winter date time    |          | Date/time for switching to winter operation. If * is indicated instead of date/time, the switch is to Outdoor air temp. suppressed  |
| Time constant       |          | Time constant for calculating Outdoor air temp. moderated. Set to 0 for 10 seconds to reset moderated outdoor air temperature. Set constantly to 0 for switching to current outdoor air temperature |
| Outs air tmp summer |          | Outdoor air temperature for switching to summer operation   |
| Outs air tmp winter |          | Outdoor air temperature for switching to winter operation   |

**> EXAMPLE**

Outdoor air temp. moderated=shows average temperature over the last X hours (24 in this case)

Date/Time summer=\*

Date/Time winter=\*

Time constant=24

Outdoor air temp. Summer=15

Outdoor air temp. Winter=10

If average temperature is over 15 degrees for 24 hours, the control system switches to summer operation. If the average temperature is under 12 degrees for 24 hours, the control system switches to winter operation. If date and time are shown instead, this will override the temperature settings and the control system will switch to date/time instead.

### 8.8. Free cooling

Night cooling works so that the unit can start and run at night to cool down the room. Configure as follows:



**Start page > Main menu > Configuration > Configuration 2 > Free cooling**

| Parameter | Function  |
|-----------|---|
| No        | Free cooling deactivated                                  |
| 12 hours  | Starts at least 12 hours before the next operating period |
| 9 hours   | Starts at least 9 hours before the next operating period  |
| 6 hours   | Starts at least 6 hours before the next operating period  |
| 3 hours   | Starts at least 3 hours before the next operating period  |
| Always    | Can be started at any time                                |



**Start page > Main menu > Configuration > Configuration 2 > Free cooling > Fan step**

|   |   |
|---|---|
| 1 | The fans run at step 1 during nighttime cooling |
| 2 | The fans run at step 2 during nighttime cooling |
| 3 | The fans run at step 3 during nighttime cooling |



**Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute**



**Start page > Main menu > Unit > Operating mode > Free cooling**

| Parameter         | Function  |
|-------------------|---|
| Room tmp setpoint | Shows the current setpoint for room/extract air (only shown when supply air regulation is configured) |
| Hysteresis        | Hysteresis for power on (Power on = Setpoint room + Hysteresis).                                      |
| Delta             | Minimum difference between room/extract air and outdoor air temperature                               |
| Min outs tmp      | Minimum permitted outdoor air temp for activating nighttime cooling                                   |
| Min run time      | Function deactivated  |
| Fan step          | Which fan step will be needed for nighttime cooling   |

## 8.9. Support operation

Nighttime support operation prevents the building from overheating or overcooling. This is regulated via a separate setpoint for heating and cooling.

The temperature test starts the unit after a long period of inactivity in order to update the duct sensor temperature. This temperature is used as a criterion for starting free cooling or support operation, and must always be kept updated.

The function is activated automatically when the following conditions are met:

### 8.9.1. To activate the function



**Start page > Main menu > Configuration > Configuration 2 > Tmp start**

| Parameter | Function  |
|-----------|---|
| No        | Function deactivated                            |
| Htg       | Function activated for heating                  |
| Clg       | Function activated for cooling                  |
| Htg+Clg   | Function activated for both heating and cooling |

After making a change in a configuration menu, RESTART



**Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute**



### 8.9.2. To configure the function



**Start page > Main menu > Unit > Operating mode > Tmp start**

| Parameter          | Function   |
|--------------------|--|
| Start stpt cooling | Start temperature for cooling, extract air > Start cooling   |
| Cooling set-point  | Supply air setpoint when support operation cooling is activated  |
| Start stpt heating | Start temperature for heating, extract air > Start cooling   |
| Heating set-point  | Supply air setpoint when support operation Heating is activated  |
| Hysteresis         | Hysteresis for power off:<br>In case of cooling: Extract air< Start cooling - Hysteresis<br>In case of heating: Extract air> Start Heating+ Hysteresis |
| Minimum off time   | Shortest power off time after activation of heating or cooling   |
| Min run time       | Shortest cycle time after start  |
| Fan step           | Which fan step will be needed for support operation  |

#### > EXAMPLE SUPPORT OPERATION COOLING

Start stpt cooling = 25 degrees

Cooling setpoint = 16 degrees

Hysteresis = 3 degrees

Minimum off time = 30 min

Min run time = 15 min

A temperature test is performed and the extract air is 26 degrees. The unit then goes into support operation cooling and regulates the supply air to 16 degrees. The unit stops when the extract air has dropped to 22 degrees (Start cooling - Hysteresis), but no earlier than 15 mins. Support operation starts again no earlier than 30 mins after the last stop.

### 8.10. Temperature test for free cooling operation


The function is used when room sensors are installed. The unit then starts up as usual to sense the temperature in the exhaust air. Used to determine whether the unit should continue in night cooling / support mode or not.

Night cooling or support operation must be activated to be able to run temperature tests. See 8.9 or 8.10 to activate the function.

 **Start page > Main menu > Configuration > Configuration 2 > Free cooling**

 **Start page > Main menu > Configuration > Configuration 2 > +Tmp start**

After making a change in a configuration menu, RESTART

 **Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute**

 **RESTART**

To allow free cooling or support operation, the unit must start up and detect the temperatures. This is configured under:

Configure as follows:

 **Start page > Main Menu > Unit > Operating mode > Fan-Kick exh tmp**

| Parameter     | Function   |
|---------------|--|
| Kick time     | Time for temperature test  |
| Interval time | How often the temperature test is to be carried out                        |
| On time       | Operating time for temperature test, <b>NB.</b> Not less than 180 seconds. |

| > EXAMPLE FREE COOLING OPERATION TEMP TEST   |  |
|--|--|
| Kick time = 23:00  |  |
| Interval time = 3  |  |
| On time = 300  |  |
| The unit is turned on for 300 seconds if it has been turned off for at least 3 hours since 23:00 |  |
| <b>NB.</b> Exercise time = 24:60 and interval time = 0.0 = no temperature test carried out.      |  |

| >EXAMPLE NIGHTTIME COOLING  |  |
|---|--|
| Setpoint room = 22  |  |
| Hysteresis = 2  |  |
| Delta = 5   |  |
| Min outdoor air temp = 10   |  |
| Min cycle time = 30   |  |
| A temperature test is performed and the room/extract air is > 24 degrees and the outdoor air temperature between 10 and 17 degrees. |  |
| The unit starts and stops only when the room/extract air is 22 degrees and at least 30 mins have passed since startup.              |  |

## 9. Fan regulation

### 9.1. Select method of regulation

#### 9.1.1. Selection fan regulation method

All fan regulation functions are selected under the menu option:

**Start page > Main menu > Configuration > Configuration 1 > Fan control mode**

| Parameter   | Funksjon  |
|-------------|---|
| Direkte     | Brukes ikke   |
| Dir.fro     | Brukes ikke   |
| Fast frekv. | Prosent styring av viftene 0-100%   |
| Trykkreg.   | Viftene regleres via trykk  |
| Flytsreg.   | Viftene reglerer via luftmengde   |
| TF slav     | Avtrekksviften reglerer via trykk og tilluftsviften reglerer avhengig av avtrekksviften |
| FF slav     | Tilluftsviften reglerer via trykk og avtrekksviften reglerer avhengig av tilluftsviften |

#### 9.1.2. Flow regulation

'Flow regulation' is selected by default. This means that the fans will regulate according to the set airflow in the control system. E.g. l/s or m<sup>3</sup>/h.

#### 9.1.3. Fixed speed

This means that the fans will regulate according to the set percentage in the control system. E.g. 50%

**Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**




Set parameters in the menu option:

**Start page > Quick menu > Setup > Setpoints/Settings**


| Parameter          | Function Mengderegulering                              | Function Fast frekvens           |
|--------------------|--|----------------------------------|
| Sply fan st 1 stpt | Airflow l/s or m <sup>3</sup> /h supply air fan step 1 | Speed in % supply air fan step 1 |
| Sply fan st 2 stpt | Airflow l/s or m <sup>3</sup> /h supply air fan step 2 | Speed in % supply air fan step 2 |
| Sply fan st 3 stpt | Airflow l/s or m <sup>3</sup> /h supply air fan step 3 | Speed in % supply air fan step 3 |
| Sply fan st 4 stpt | Airflow l/s or m <sup>3</sup> /h supply air fan step 4 | Speed in % supply air fan step 4 |
| Sply fan st 5 stpt | Airflow l/s or m <sup>3</sup> /h supply air fan step 5 | Speed in % supply air fan step 5 |
| Extr fan st 1 stpt | Airflow l/s or m <sup>3</sup> /h supply air fan step 1 | Speed in % supply air fan step 1 |
| Extr fan st 2 stpt | Airflow l/s or m <sup>3</sup> /h supply air fan step 2 | Speed in % supply air fan step 2 |
| Extr fan st 3 stpt | Airflow l/s or m <sup>3</sup> /h supply air fan step 3 | Speed in % supply air fan step 3 |
| Extr fan st 4 stpt | Airflow l/s or m <sup>3</sup> /h supply air fan step 4 | Speed in % supply air fan step 4 |
| Extr fan st 5 stpt | Airflow l/s or m <sup>3</sup> /h supply air fan step 5 | Speed in % supply air fan step 5 |

### 9.2. Pressure control

Before selecting pressure control, one or two pressure sensors must be mounted and connected to the unit. If pressure sensors from Flexit are used, these must be connected to P5 and P4, see accessories manual. When using other makes, these should be connected to Block P12, see table.




Then go in via the control panel to configure the system for pressure control.

 **Start page > Main menu > Configuration > Configuration 1 > Fan control mode**

| Parameter | Function  |
|-----------|---|
| Pressure  | Requires two pressure sensors. The fans regulate individually towards their own setpoints   |
| SplySlave | Requires one pressure sensor on the extract air fan. The supply air fan follows the extract air fan with an adjustable slave offset |
| ExtrSlave | Requires one pressure sensor on the supply air fan. The extract air fan follows the supply air fan with an adjustable slave offset  |

After making a change in a configuration menu, RESTART.

 **Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**



If the unit starts up and alerts "Config error", restart the controller once again (using the same search path as above).

### 9.2.1. Configuration of measurement ranges in pressure sensors

 **Start page > Main menu > Configuration > Configuration IOs > Pressures / flows > Supply air pressure**

| Parameter  | Function  |
|------------|---|
| X7 500Pa   | X7 = Physical input (must not be changed). 500Pa = Max. set value of connected pressure sensor. |
| Type 0-10V | Type of signal. Must not be changed.  |

 **Start page > Main menu > Configuration > Configuration IOs > Pressures/flows > Extract air press**

| Parameter  | Function  |
|------------|---|
| X8 500Pa   | X8 = Physical input (must not be changed). 500Pa = Max. set value of connected pressure sensor. |
| Type 0-10V | Type of signal. Must not be changed.  |

#### Setpoint adjustment of pressure.

If Supply Fan or Extract Fan are selected as slaves, only three setpoint steps will be shown.

 **Start page > Quick menu > Setup > Setpoints/Settings**

| Parameter          | Function                              |
|--------------------|---------------------------------------|
| Sply fan st 1 stpt | Setpoint supply air fan speed 1 i Pa  |
| Sply fan st 2 stpt | Setpoint supply air fan speed 2 i Pa  |
| Sply fan st 3 stpt | Setpoint supply air fan speed 3 i Pa  |
| Extr fan st 1 stpt | Setpoint extract air fan speed 1 i Pa |
| Extr fan st 2 stpt | Setpoint extract air fan speed 2 i Pa |
| Extr fan st 3 stpt | Setpoint extract air fan speed 3 i Pa |

When selecting Supply Fan slave or Extract Fan slave for the fan regulation type, an offset must be set for the selected fan to regulate towards. Supply/extract air fans are pressure regulated. The supply/extract airflow is calculated and regulated towards the slave offset, see e.g.

 **Start page > Quick menu > Setup > Setpoints/Settings > All settings > Fan control**

#### Explanation:


The offset indicates the difference between the master fan and the slave fan.

| > EXAMPLE OFFSET |  |
|------------------|--|
| Ex 1.            | If the offset is 0 l/s, the slave fan will operate with the same airflow as the master fan.              |
| Ex 2.            | If the offset is -100 l/s, the slave fan will operate with an airflow 100 l/s less than the master fan.  |
| Ex 3.            | If the offset is 100 l/s, the slave fan will operate with an airflow 100 l/s higher than the master fan. |

After setting the offset, it may be necessary to adjust the alarm limit for airflow deviations and the acceleration amplification factor on the fan.

### 9.3. External setpoint fan

The fans can be controlled directly via an analogue 0-10V input on the control system. A min and max speed/ airflow are defined corresponding to 0 and 10V on the input.



Activated via the following menu choice:

**Start page > Main menu > Configuration > Configuration 2 > Ext. Fan setpoint**

| Parameter | Function   |
|-----------|--|
| No        | Not activated:   |
| Supply    | External control of supply air fan                       |
| Extract   | External control of extract air fan                      |
| Sply+Extr | External control of both supply air and extract air fans |

After making a change in a configuration menu, RESTART.

**Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute**



The function has two operating modes:

1. Relative A basic airflow via steps 1, 2 or 3 for fan operation + relative
2. Absolute The fan is controlled solely by the 0-10V input and steps 1, 2 and 3 become inactive.

**Start page > Main menu > Configuration > Configuration 2 > Ext stpt funct.Sply  
Ext stpt funct.Exh**

| Parameter | Function   |
|-----------|--|
| Relative  | Example of relative.<br>Relative is set to 0V = 0l/s and 10V = 500l/s<br>Step 1 is set to 100 l/s and the input for external setpoint is 0V. The fan will run at 100 l/s<br>Step 2 is set to 300 l/s and the input for external setpoint is 10V. The fan will run at 800 l/s |
| Main      | Example of Main.<br>Main is set to 0V = 100l/s and 10V = 1000l/s<br>The input for external setpoint is 0V. The fan will run at 100 l/s<br>The input for external setpoint is 5V. The fan will run at 500l/s  |

After making a change in a configuration menu, RESTART.



**Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute**



After the restart, the unit starts with an alarm: "External setpoint Supply Fan + Extract Fan conf. error" This means that one or two physical inputs need to be defined for the function. This is done via:



**Start page > Main menu > Configuration > Configuration IOs > Other > Ext. setp. SplyFan**

| Parameter | Function  |
|-----------|---|
| X6        | Defines which input the function should be connected to |



**Start page > Main menu > Configuration > Configuration IOs > Other > Exh.fan Ext. Setp**

| Parameter | Function  |
|-----------|---|
| X7        | Defines which input the function should be connected to |

After making a change in a configuration menu, RESTART.



**Start page > Main menu > Configuration > Configuration IOs > Restart required! > Execute**





### 9.3.1. Parameter settings for Comp.



**Start page > Quick menu > Setup > Setpoints/Settings > All settings > Fan control > Supply fan/Extract fan**

| Parameter                         | Function  |
|-----------------------------------|---|
| Act supply stpt                   | Shows the current setpoint for the supply air/extract air fan, including compensation |
| Act extract stpt                  |   |
| Stage 1                           | Setpoint supply air/extract air fan speed 1   |
| Stage 2                           | Setpoint supply air/extract air fan speed 2   |
| Stage 3                           | Setpoint supply air/extract air fan speed 3   |
| Ext stpt curve Y1 - Present value | Scaling of 0-10V signal, speed/airflow at 0V  |
| Ext stpt curve Y2 - Present value | Scaling of 0-10V signal, speed/airflow at 10V   |
| External setpoint Supl.fan        | Shows the current setpoint for the 0 -10V input                                       |
| Exh.fan                           |   |


### 9.3.2. Parameter settings for Main



**Start page > Quick menu > Setpoints/Settings > All settings > Fan control > Supply air fan/Extract air fan**

| Parameter                         | Function   |
|-----------------------------------|--|
| Act supply stpt                   | Shows the current setpoint for the Supply air/Extract air fans |
| Act extract stpt                  |  |
| Stage 1                           | Not active   |
| Stage 2                           | Not active   |
| Stage 3                           | Not active   |
| Ext stpt curve Y1 - Present value | Scaling of 0-10V signal, speed/airflow at 0V                   |
| Ext stpt curve Y2 - Present value | Scaling of 0-10V signal, speed/airflow at 10V                  |
| External setpoint Supl.fan        | Shows the current setpoint for the 0 -10V input                |
| Exh.fan                           |  |

## 9.4. External fan control via digital inputs



| Block no. | Function              |
|-----------|-----------------------|
| 23        | Eksternstyring 1 (DI) |
| 24        | Eksternstyring 1 (GO) |
| 25        | Eksternstyring 2 (DI) |
| 26        | Eksternstyring 2 (GO) |
| 28        | Eksternstyring 3 (GO) |
| 34        | Eksternstyring 3 (DI) |

Connection of signal(s) for controlling fan speeds from external components. It is possible to connect various types of switch/sensor that have pulsed or fixed positions. By default the regulator is set for switches with fixed values.

The prioritization between the inputs is that the unit regulates at the most recently activated speed.

| Parameter              |              |  |
|------------------------|--------------|--|
| External control 1     | ON = Speed 1 | Used for night set-back/when the room is not in use                        |
| External control 2     | ON = Speed 2 | Used for regular day-time operation  |
| External control 3     | ON = Speed 3 | Used for higher occupancy of the room, such as person/humidity loads, etc. |
| External control 1 & 2 | ON = Stop    | Used when the room remains empty for extended periods                      |
| External control 1 & 3 | ON = Speed 4 | Can be used for imbalance, e.g. forced exhaust                             |
| External control 2 & 3 | ON = Speed 5 | Can be used for imbalance, e.g. forced supply                              |

## 9.5. Fire fan

The unit has a potential-free output for controlling an external fire fan. This requires the installation of an SP90 expansion module.



## 10. Connection of external equipment

### 10.1. Fire damper

The unit is able to control and exercise fire dampers. Fire dampers can be included in the unit control; either via autotest or always open. Monitoring of defined end positions is carried out. The current status and operating mode of the fire damper is displayed.

To activate the function.

**Start page > Main menu > Configuration > Configuration 1 > Fire damper**

| Parameter    | Function  |
|--------------|---|
| No           | Function deactivated  |
| Yes          | Function activated The fire damper will remain open even when the unit has stopped.               |
| FollowUnit   | Function activated The fire damper is opened when the unit starts and closed when the unit stops. |
| 2-4          | Not used  |
| 2-4+FollUnit | Not used  |

After making a change, a restart must be carried out.

**Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**



Continue configuring the fire damper feedback.


**Start page > Main menu > Configuration > Configuration 2 > Fire damper fdbk**

| Parameter | Function  |
|-----------|---|
| Closed    | Only one reset for closed damper with NC input  |
| Clsd+Opnd | Not used  |
| Combined  | Resets for open and closed position, but only one signal/input with a sequence as follows: 1 (closed) ---> 0 (closes/opens) ---> 1 (open) |
| Clsd.Inv  | Only one reset for closed damper with NO Invert input   |


After making a change in a configuration menu, RESTART.



**Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute**



Example of connection description for fire damper indication with combined signal for open and closed.



Fire dampers can be included in the unit control;



**Start page > Main menu > Unit > Damper control > Fire damper cmd**

| Parameter                          | Value  | Function  |
|------------------------------------|--|---|
| Operation                          | Off  | Current status for outdoor air damper.  |
|                                    | On   | Go to page for all settings of digital outputs.   |
| Feedback opened<br>Feedback closed | OK   | Active reset if the damper is closed. This must always be set.  |
|                                    | 1 / 2 / 3 / 4<br>+ all possible combinations | The numbers indicate which damper has an error.<br>There is only an input for one damper in the control system.                             |
| State                              | N/A  | Only possible during configuration  |
|                                    | Closed                                       | Closed  |
|                                    | Cl/Op  | Closes/opens.   |
|                                    | Open   | Open See example below  |
| Mode                               | N/A  | Only possible during configuration  |
|                                    | OK   | OK  |
|                                    | Test   | Test mode.  |
|                                    | Alarm  | Alarm mode  |
| Opening time                       | 1...600 [s]                                  | Time for damper opening (see product sheet for damper actuator).  |
| Closing time                       | 1...600 [s]                                  | Time for damper closing (see product sheet for damper actuator).  |
| Start manual test                  | Passive                                      | Activate fire damper test manually.   |
|                                    | Active                                       |   |
| Auto test date/<br>time            | Time, Day of week, Date                      | Time of automatic start of damper test<br>The autotest is deactivated for Configuration 1 > Fire damper = Yes+FollUnit<br>See example below |
| Auto test interval                 | 0...36000 [h]                                | Time interval for automatic damper test.<br>See example below   |

> EXAMPLE DAMPER COMMAND 0 -> 1:

|   |   |
|---|---|
| When the damper has received a signal to start opening, the damper feedback must give an "open signal" within 15% of the set opening time.  | Otherwise an alarm is triggered for lack of movement.                         |
| When the damper has received a signal to start opening, the damper feedback must give a "close signal" within 115% of the set opening time. | Otherwise a reset alarm is triggered for open position Damper command 1 -> 0. |

> EXAMPLE DAMPER COMMAND 0 -> 1:

|  |   |
|--|---|
| When the damper has received a signal to start closing, the damper feedback must give an "open signal" within 15% of the set closing time. | Otherwise an alarm is triggered for lack of movement.                         |
| When the damper has received a signal to start closing, the damper feedback must give a "close signal" within 15% of the set opening time. | Otherwise a reset alarm is triggered for open position Damper command 1 -> 0. |

Automatic testing can be carried out at a certain time (day, time) and/or at a certain interval.

> EXAMPLE TEST INTERVAL:

|  |   |
|--|---|
| Auto test date/time = *.* *;*.*/ Auto test interval = 24     | The test is performed every 24 hours, whatever the time of day.   |
| Auto test date/time = 23.* Mo,*.*/ Auto test interval = 47 h | The test is performed every month at 23:00, with the previous test having been held at least 47 hours previously. |
| Auto test date/time = *.* *;*.*/ and Auto test interval = 0  | No automatic test is carried out.<br>Test sequence = 1  |

Test mode: The entire aggregate stops. After the period Deferral delay. the outdoor air and exhaust air dampers are closed and fire damper tests are initiated.

The test is run according to the above example of damper maneuver. If everything works as intended, the unit will start up again. Otherwise, the unit continues to stop and an alarm on an incorrect fire damper is activated.

## 10.2. Fire/smoke detector

The unit can have two fire alarms (Fire alarm 1 and Fire alarm 2). Both have the same settings, but may have different functions, for example, one may stop the fans, and the other may force. Fire alarm 1 has the highest priority. Both are described below as 1 and 2.

**Start page > Main menu > Configuration > Configuration 1 > Fire alarm 1 (2)**

| Parameter | Function  |
|-----------|---|
| No        | No fire alarm   |
| Alarm     | External fire alarm such as smoke detectors, thermostat, fire alarm control centre, etc.  |
| Tmp       | Internal fire alarm via measurement of normal supply air and extract air temperature when both sensors are accessible. A fire alarm is triggered when one of the two temperatures reaches a specific value. |
| Alarm+Tmp | Both fire alarms.   |

After making a change in a configuration menu, RESTART.

**Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**



If Fire alarm 2 is configured in, it must be connected to an input. If there are no free inputs available, one must use an input that is already connected to another function, such as Digital speed input 3 (DI3) located at P12-34. If it is in use, contact Flexit to determine which input can be used. To be able to use P12-34, the function DI3 must be removed from this input. This is done as follows:

**Start page > Main menu > Configuration > Configuration 1 > Ext control input = 2**

After changing a configuration menu, a restart should be performed.

**Start page > Main menu > Configuration > Configuration 1 > Restart required! > Execute**



Configure the Fire Alarm 2 function to the input where Speed Input 3 was configured by going to the following:

**Start page > Main menu > Configuration > Configuration IOs > Digital alarms > Fire alarm 2 = D1**

On choice of Tmp or Alarm+Tmp, the alarm limits for temperatures are configured as follows:


**Start page > Quick menu > Setup > Setpoints/Settings > All settings > Alarm limit set**

| Parameter              | Function   |
|------------------------|--|
| Supply tmp lim fire 1  | Alarm limit too high supply air temperature. Fire alarm 1  |
| Extract tmp lim fire 1 | Alarm limit too high extract air temperature. Fire alarm 1 |
| Supply tmp lim fire 2  | Alarm limit too high supply air temperature. Fire alarm 2  |
| Extract tmp lim fire 2 | Alarm limit too high extract air temperature. Fire alarm 2 |

On choice of Tmp or Alarm+Tmp, the fan regulation is configured as follows.

**Start page > Main menu > Unit > Fan control > Firemode 1 (2)**

| Parameter | Function   |
|-----------|--|
| Stop      | The fans stop in case of fire.                                       |
| Run Sply  | The Supply air fan runs at max. set step, the Extract air fan stops. |
| Run Exh   | The Extract air fan runs at max. set step, the Supply air fan stops. |
| Run both  | Both fans run at the max set step.                                   |



The input is normally open (NO) and triggers an alarm when closed. This can be reconfigured to normally closed (NC) via:

**Start page > Main menu > Unit > Inputs > Fire 1 (2) > Contact function**

| Parameter | Function  |
|-----------|---|
| NO        | Normally open - triggers alarm if input is closed.  |
| NC        | Normally closed - triggers alarm if input is opened |

Scaling of CO<sub>2</sub> sensor.



**Start page > Main menu > Configuration > Configuration IOs > Other > Air quality sensor**

| Parameter          | Value    | Function   |
|--------------------|----------|--|
| Air quality sensor | X4       | This is the physical input on the regulator and must not be changed.         |
| Scale              | 2000 ppm | This is the upper limit on the CO <sub>2</sub> sensor. At 10V on the output. |

### 10.3. Air quality CO<sub>2</sub>/CO

Fans (see Fan compensation) are regulated by air quality. The outdoor air volume increases when the carbon dioxide content exceeds a certain value (fan speed increases and the circulation volume decreases if a bypass damper has been installed). The outdoor air volume goes down when the carbon monoxide content exceeds the set value (fan speed decreases and circulation volume goes up).

**Start page > Main menu > Configuration > Configuration 2 > Fan comp air qual = Yes**


After making a change in a configuration menu, RESTART.

**Start page > Main menu > Configuration > Configuration 2 > Restart required! > Execute**



**Start page > Main menu > Unit > Air quality control**

| Parameter  | Value          | Function  |
|------------|----------------|---|
| Controller | 0...100[%]     | Current regulator value. Go to page for regulator settings. |
| Function   | Normal         | Normal for CO <sub>2</sub>                                  |
|            | Inverted       | Inverted for carbon monoxide.                               |
| Setpoint   | 0...3000 [ppm] | Setpoint for air quality regulation.                        |



| Block no. | Function |
|-----------|----------|
| 1         | L 230V   |
| 2         | N 230V   |
| 29        | (0-10V)  |
| 30        | (G0)     |
| 32        | 24VAC    |

#### Parameter

The setpoint is set to 800 ppm and the CO<sub>2</sub> sensor detects an actual value of 1000 ppm. The unit switches up to speed 3 and runs at this speed until the CO<sub>2</sub> sensor detects an actual value of under 800 ppm, when it switches down to the speed set for the current time channel.

### 10.4. AUX Damper

The output signal is affected by the speed at which the ventilation unit is operating. The function can be used, e.g., to open a damper when the unit switches to a higher speed. The function must be activated in the control system. This is done via the following menu option.

**Start page > Main menu > Configuration > Configuration 2**

| Parameter       | Value     | Function  |
|-----------------|-----------|---|
| Aux Analog outp | No        | Analogue aux. output that generates a 0-10V signal, depending on current fan step.  |
|                 | Fan       | Output signals can be set for each fan step. E.g. 10% at step 1 and 60% at step 2.  |
|                 | AdjDiscrg | The output signal will depend on the difference between the supply air temp and the room temp. The setting will determine the difference which will result in 0V and 10V. E.g., Supply air temp-room temp = 5 degrees gives a 7V output signal. |


After making a change in a configuration menu, RESTART

**Start page > Main menu > Configuration > Configuration 2 > Restart**

**RESTART**

**Start page > Main menu > Unit > Auxiliary**

| Parameter  | Function  |
|------------|---|
| Fan step 0 | Aux. output signal for unit shutdown (also in case of unit malfunction).  |
| Fan step 1 | Aux. output signal for active fan step 1 (setpoint 1 for regulated fans). |
| Fan step 2 | Aux. output signal for active fan step 2 (setpoint 2 for regulated fans). |
| Fan step 3 | Aux. output signal for active fan step 3 (setpoint 3 for regulated fans). |



### 10.5. AUX operating mode indicator


The function of the digital output can be selected. By default, this is the buzzer alarm, but other functions can be selected. See table.

**Start page > Main menu > Configuration > Configuration 2 > Aux. operating mode starts > Yes**


**Start page > Main menu > Configuration > Configuration 2 > Restart**

**Start page > Main menu > Unit > Auxiliary > Operating mode indic. selection**

| Step                 | Measure   |
|----------------------|---|
| Off                  | System switched off.  |
| On/comfort           | The unit is switched on or comfort operation.   |
| Economy              | Economy operation   |
| Manual:              | Manual control activated.   |
| Osstp                | Optimum start activated optimisation function).   |
| Nighttime cooling    | Nighttime cooling activated.  |
| Support operation    | Support operation activated.  |
| Test temp            | Temperature test activated.   |
| Damper exercise      | Fire damper test activated.   |
| Fire                 | Fire alarm activated; the system is in fire alarm mode.   |
| Stop                 | The unit has stopped and has been blocked.  |
| Operation            | The unit is in operation (Supply air/Co/Ec/Osstp/ Nighttime cooling/Support operation/TestTemp/ Startup). |
| Full heating         | Hot water or electric heating register with 100% capacity.  |
| Full recovery        | Heating recovery (plate, rotary, water heat exchanger) with 100% capacity.                                |
| Full cooling         | Cooling with 100% capacity.   |
| Summer               | Indicates that the control system is in summer operation.   |
| Winter               | Indicates that the control system is in winter operation.   |
| Heating requirements | Indicates that the control system has a requirement for heating (both rotor and/or heating).              |
| Normal operation     | Indicates that the control system is in normal operation, no alarms or overrides.                         |



# 11. Internet



The unit can be controlled via the Internet. This is done by joining the regulator to a network. This is then connected by entering the regulator's IP address into a computer web browser.

To configure the function, access the following:

**Start page > Main menu > Communication overview > IP-Config > DHCP**

| Parameter | Function  |
|-----------|---|
| Active    | The regulator is assigned an IP address from the network. |
| Passive   | A fixed IP address is entered in the regulator.           |

Information on other settings in the communications menu can be obtained from personnel with network responsibility.

After making a change in a configuration menu, RESTART.

**Start page > Main menu > Communication overview > IP-Config. > Restart**



After restart, go into:

**Start page > Main menu > Communication > IP-Config.**

and note **Current IP**.

Open the web browser on a computer connected to the same local network as the unit and enter the IP number in the address field. To log into the web page, use the following information.

**Username:** ADMIN  
**Password:** SBTAdmin!

Then enter the password 2000 to access the regulator.

## 12. ModBus TCP/IP & RS485

The unit can be controlled via ModBus, either via TCP/IP or RS485 (RTU) as a standard function in the regulator.

To configure the TCP/IP function, access the following:

 **Start page > Main menu > Communication > IP-Config > DHCP**

| Parameter | Function  |
|-----------|---|
| Active    | The regulator is assigned an IP address from the network. |
| Passive   | A fixed IP address is entered in the regulator.           |

Information on other settings in the communications menu can be obtained from personnel with network responsibility.

After making a change, a restart must be carried out.


 **Start page > Main menu > Communication overview > IP-Config > Restart**



After restart, go to:

 **Start page > Main menu > Communication > IP-Config.**

and note **Current IP**.



The ModBus parameter list is available for downloading on [www.flexit.com](http://www.flexit.com)

To configure RS485 (RTU), access the following:

 **Start page > Main menu > Communication > ModBus RTU (RS485)**

| Parameter     | Function   |
|---------------|--|
| Slave address | Select slave address (1...247): Enter the corresponding ModBus slave address |
| +RS485:1      | Used internally.   |

| Parameter        | Function   |
|------------------|--|
| +RS485:2         | Enter the output for the regulator   |
| Baud rate        | Select transfer speed:   |
| Parity           | Select parity: No, even or odd parity  |
| Stop bit         | Select stop bits: One or two stop bits   |
| Delay            | Delay between question sent and bus reply  |
| Response timeout | Select response timeout: Settings access time for master Master must provide read access within this period, otherwise an alarm is triggered |
| Unit alarm       | What type of alarm   |
| Alarm address    | Which slave issues the alarm   |



### 13. Climatix Scope Light

There is a complete Modbus list available for download on Flexit's website. All functions are enabled there. If you want a list containing only the configured functions for the specific unit, you must retrieve it from the controller using Climatix Scope Light.

The controller has different Modbus configurations depending on which functions are activated in the menus. Therefore, it is important that the controller is fully configured before the Modbus list is retrieved.

1. To retrieve the current Modbus list from the controller, use a program called Climatix Scope Light, which can be downloaded from the website [www.flexit.com](http://www.flexit.com).



2. Unzip the Zip file and start by installing:



3. Install thereafter:




4. Start the program:



5. Connect the computer to the controller via the USB port (Micro-USB):




6. Click on på "Settings".




7. Set "Target", "Interface" and "Device" as shown. For "Auth" enter password: SBTAdmin!

Then press "Connect"


Enter 2000 as pin code in the popup window.




8. Select "Documentation".



9. Right-click in the "description" field and select "New".



10. Fill in "Virtual Member" and "Language" as shown in the picture and click "OK".



11. The current tag list opens as a PDF on the computer.

| Object name               | Dimension   | Start Register | Data Type     | Scale |
|---------------------------|---|----------------|---------------|-------|
| TopPact - PresentValue    | >MS<br>>MMap<br>>MMapTag  | 3a0120         | unsigned word | 1.0   |
| TopSteps - PresentValue   | >MS<br>>MMap<br>>MMap   | 3a0121         | unsigned word | 1.0   |
| FanOnsMode - PresentValue | >MS<br>>MMapTag<br>>MMapTag<br>>MMapTag<br>>MMapTag<br>>MMapTag             | 3a0122         | unsigned word | 1.0   |
| TopOnsMode - PresentValue | >MS<br>>MMapTag<br>>MMapTag<br>>MMapTag<br>>MMapTag<br>>MMapTag<br>>MMapTag | 3a0123         | unsigned word | 1.0   |
| FacIn - PresentValue      | >MS<br>>MMap<br>>MMap<br>>MMap<br>>MMapTag                                  | 3a0124         | unsigned word | 1.0   |
| FacFdbk - PresentValue    | >MS<br>>MMap<br>>MMap<br>>MMap<br>>MMapTag                                  | 3a0125         | unsigned word | 1.0   |
| OnTopOnp - PresentValue   | >MS<br>>MMap  | 3a0127         | unsigned word | 1.0   |
| TopSprfda - PresentValue  | >MS<br>>MMapTag<br>>MMapTag<br>>MMapTag                                     | 3a0128         | unsigned word | 1.0   |
| ComTesta - PresentValue   | >MS<br>>MMap  | 3a0129         | signed word   | 1.0   |
| ComTest - PresentValue    | >MS<br>>MMap<br>>MMap   | 3a0130         | signed word   | 1.0   |
| ComTest - PresentValue    | >MS<br>>MMap<br>>MMap   | 3a0131         | signed word   | 1.0   |
| ManualMode - PresentValue | >MS<br>>MMap<br>>MMap   | 3a0132         | signed word   | 1.0   |
| ManualMode - Manual       | >MS<br>>MMap<br>>MMap   | 3a0133         | signed word   | 1.0   |
| AlaC11 - PresentValue     | >MS<br>>MMap<br>>MMap   | 3a0134         | signed word   | 1.0   |
| AlaC11 - PresentValue     | >MS<br>>MMap<br>>MMap   | 3a0135         | signed word   | 1.0   |
| AlaC11 - PresentValue     | >MS<br>>MMap<br>>MMap   | 3a0136         | signed word   | 1.0   |

## 14. Heating/cooling via heat pump

The control system is able to control a heat pump for heating and cooling, which is connected to a ducted coil. It can be used both as a free-standing unit or in sequence beforehand with the internal electric coil, which can then be used as peak heating and/or as reserve heating while the heat pump is defrosting.

To adjust the transition between summer and winter operation, see chap. 8.5.

**For the function to operate, I/O module SP90 must be installed and configured. See accessories manual**

**If you wish to use the internal electric-powered coils, these must be installed/configured as shown in the manual supplied with the coils.**

### 14.1. Configuration of control system

**Start page > Main menu > Configuration > Configuration 1 > Water Heating 2**

| Parameter           | Function  |
|---------------------|---|
| Yes                 | Additional heating activated  |
| +PreH Outside-Temp. | Additional heating with preheating based on outdoor air temperature. Analogue heating valve output. |
| +PreH Frost-Temp    | Additional heating with preheating based on frost protection temperature.                           |
| ModBus              | Switches between analogue output and Siemens ModBus valve   |

Select 'Yes' to activate the function and then 'Ready'.

**Start page > Main menu > Configuration > Configuration 1 > Cooling 2**

| Parameter | Function  |
|-----------|---|
| Water     | Additional cooling via 0-10V signal                       |
| HP 1step  | Additional cooling Off/On 1 step                          |
| HP 2step  | Additional cooling Off/On 2 step                          |
| HP 3step  | Additional cooling Off/On 3 step                          |
| ModBus    | Switches between analogue output and Siemens ModBus valve |

Select 'Water' and then Ready to activate the 0-10V output signal for the function. After making a change in a configuration menu, RESTART.

**Start page > Main menu > Configuration > Configuration 1 > Restart**



The unit will show an alarm on startup. This can be removed by the configuration shown further down.

**Start page > Main menu > Configuration > Configuration 2 > Water Heating 2 pump**

| Parameter | Function                                |
|-----------|---|
| No        | No Off/On signal to pump                |
| Yes       | Off/On signal to pump                   |
| Yes+Kick  | Off/On signal to pump + exercise motion |

**Start page > Main menu > Configuration > Configuration 2 > HP Defrost**

Select 'Yes' on both heating and cooling. Use to signal a heating/cooling requirement to the heating pump.

**Start page > Main menu > Configuration > Configuration 2 > HP Defrost**

| Parameter | Function                        |
|-----------|---------------------------------|
| No        | Defrosting function deactivated |
| Yes       | Defrosting function activated   |

Select 'Yes'. Used to lock the output signal to the heat pump and if necessary activate electric heating (if connected) when defrosting the heat pump.

**Start page > Main menu > Configuration > Configuration 2 > Water heating 2 control**

| Parameter      | Function  |
|----------------|---|
| StandAlone     | Regulation seeks its own temperature setpoint               |
| Seq H-Heating2 | Regulation uses the sequence electrical heating - heat pump |
| Seq Heating2-H | Regulation uses the sequence heat pump -electrical heating  |

Select 'Seq Heating2-H' to force the regulation to operate using the sequence Heat pump first and electrical heating second.

**Start page > Main menu > Configuration > Configuration 2 > Cooling 2 control**

| Parameter  | Function   |
|------------|--|
| Standalone | Regulation seeks its own temperature setpoint                            |
| Sequence   | Regulation uses the sequence before or after ordinary cooling regulation |

Select "Sequence" to force the regulation to operate in sequence with heat recovery and heating.

 **Start page > Main menu > Configuration > Configuration 2 > Combi-coil**

| Parameter  | Function  |  |
|------------|---|--|
| Combi-coil | Selection of coil function for both heating and cooling |  |
|            | Normal seq.   | One coil for both heating and cooling  |
|            | Extra seq.  | A coil which can be run as extra heating and extra cooling   |
|            | 1Valve<br>1Pump   | Coil with combined valve for regulating heating and cooling. One digital output for switching between heating and cooling. |
|            | 2Valves<br>1Pump  | Coil with separate valves for regulating heating and cooling. One digital output for switching between heating and cooling |
|            | Heat pump   | Coil with three separate outputs, one analogue and two digital.  |
|            | DX Com  | Heating pump connection via process bus  |
|            | Inv. valve  | Analogue output signal inverted  |

Select 'Extra seq' and then Ready to send the same signal (0-10V) to the heat pump for both heating and cooling.  
After making a change in a configuration menu, RESTART.

 **Start page > Main menu > Configuration > Configuration 2 > Restart**



After restarting, an alarm will appear on the regulator requiring configuration of which input is connected to the heat pump defrosting function. This is done via:

 **Start page > Main menu > Configuration > Configuration IOs > Digital inputs > HP Defrost**


| Parameter | Function     |
|-----------|--------------|
| D4        | Block P12-35 |

Select 'D4' This will connect block P12-35 on the A2 circuit board to the function. The input is also used for resetting the fire damper. If both functions are used, contact Support to configure a new input.

For the output that alternates between heating and cooling to work, the pump output must be configured differently.


 **Start page > Main menu > Unit > Outputs > Heating 2 pump cmd > Contact function > NO/NC**

Set this to NO

 **Start page > Main menu > Unit > Outputs > Cooling 2 pump cmd > Contact function > NO/NC**

Set this to NC

## 14.2. Installation






**Start page > Main menu > Unit > Temperature regulation > Temp control > Heating 2 > HP Deifr. Block EI-Htg**

The standard setting is 60 seconds.

## 15. Combi battery

The unit is able to control a combined liquid coil which is operated as heating coil in winter and a cooling coil in summer. Make sure that valves and pump and frost guard are connected as instructed below.

### 15.1. Installation



## 15.2. Configuration

Then go in via the control panel to configure the unit as described below.



**Start page > Main menu > Configuration > Configuration 1 > Type of Heater**

| Parameter | Function                              |
|-----------|---------------------------------------|
| Water     | Water heating without preheating coil |



**Start page > Main menu > Configuration > Configuration 1 > Cooling**

| Parameter | Function                           |
|-----------|------------------------------------|
| Water     | Analogue output for liquid cooling |



**Start page > Main menu > Configuration > Configuration 1 > Restart**



Then select for heating and cooling to operate in normal sequence, with a combined regulator valve for both heating and cooling.



**Start page > Main menu > Configuration > Configuration 2 > Combi coil**

| Parameter   | Function   |
|-------------|--|
| 1 Active    | One coil for both heating and cooling  |
| 1Vlv<br>1Pu | Coil with combined valve for regulating heating and cooling. One digital output for switching between heating and cooling. |



**Start page > Main menu > Configuration > Configuration 2 > Restart**





## 16. Programming of ModBus fans

The ProNordic units have ModBus communication between the fans and the automation system. If a fan needs to be replaced, the spare fan must be addressed so that the automation system knows whether it is a supply or exhaust fan.



**ProPanel V4.14.00-**

Valid version from V4.14.00 and higher.

To set the current version go to:



**Start page > Main menu > System objects  
> Versions = V4.14.00**

1. Make sure the power is switched off and replace the defected fan. **ATTENTION!** If both fans are to be replaced, connect only one fan at the time.
2. Make sure you know if it is the supply air fan or extract air fan you replaced.
3. Switch the power on.
4. If you are not logged in, log in with password: 6000



**Start page > Main menu > Enter PIN =  
6000**

5. Make sure "SERVICE SWITCH" is set to "OFF".



**Start page > SERVICE SWITCH > Off**

6. The unit must be put into configuration mode for a new fan to be programmed



**Start page > Main menu > Configuration  
> Configuration IOs > Intergrations >  
Configuration IOs = Not done**

7. Go back to Configuration IOs and scroll down to "Restart required" select "Execute". For the device to enter configuration mode.



**RESTART**

8. Once your device has restarted, go to:



**Start page > Main menu > Configuration  
> Configuration IOs > Integrations > Fan  
configuration**

9. Select the fan you want to configure (Supply air or Extract air).  
"Supl.Fa 1"=Supply air fan  
"Extr.Fa 1"=Extract air fan  
("Supl.Fa 2" and "Extr.Fa 2" are only valid for units S340 and L350)
10. Wait until the selected fan first appears to the right of "+ Fan configuration." and then changed to «Success» on same place.
11. Now the fan is configured. If the second fan is also to be replaced, connect it and go to point 9 again.
12. When the fan(s) are added press "+ Fan configuration." again and select "Done".
13. Wait until "Done" appear on the right side of "+ Fan configuration".
14. Now the fan(s) are configured to work with the device. Set the configuration mode to complete.



**Start page > Main menu > Configuration  
> Configuration IOs > Intergrations >  
Configuration IOs = Done**

15. Go to «Restart required " at the line below and select "Execute".



**RESTART**

16. After restarting the device, set "SERVICE SWITCH" to "AUTO" and check the function.



**Start page > SERVICE SWITCH = Auto**





**ProTouch V4.14.00-**

Valid version from V4.14.00 and higher.  
To set the current version go to:



**Start page > Main menu > System objects > Versions = V4.14.00**

1. Make sure the power is switched off and replace the defected fan. ATTENTION! If both fans are to be replaced, connect only one fan.
2. Make sure you know if it is the supply air fan or extract air fan you replaced.
3. Switch on the power.
4. If you are not logged in, log in with password: 6000. Then go to Operations.
5. Make sure "SERVICE SWITCH" is set to "OFF".



**Start page > SERVICE SWITCH > Off**

6. Push "Confirm".
7. The unit must be put into configuration mode for a new fan to be programmed.



**Main menu > Configuration > Configuration IOs > Integrations > Fan configuration = Not done**

8. Push "Confirm".
9. Go back to Configuration IOs and scroll down to "Restart required" select "Execute". For the device to enter configuration mode.
10. Once your device has restarted, go to:



**Main menu > Configuration > Configuration IOs > Integrations > Fan configuration**

11. Select the fan you want to configure (Supply air or Extract air) and push "CONFIRM".  
"Supl.Fa 1"=Supply air fan  
"Extr.Fa 1"=Extract air fan  
("Supl.Fa 2" and "Extr.Fa 2" are only valid for units S340 and L350)
12. Wait until the selected fan first appears to the right of "+ Fan configuration." and then changed to «Success» on same place.
13. Now the fan is configured. If the second fan is also to be replaced, connect it and go to point 9 again.
14. When the fan(s) are added press "+ Fan configuration." again and select "Done".
15. Wait until "Done" appear on the right side of "+ Fan configuration".
16. Now the fan(s) are configured to work with the device. Also set the configuration mode to complete.



**Main menu > Configuration > Configuration IOs > Configuration IOs = Done**

17. Push "Confirm".
18. Go to «Restart required " at the line below and select "Execute".



19. After restarting the device, set "SERVICE SWITCH" to "AUTO" and check the function.



**Start page > SERVICE SWITCH = Auto**

20. Push "Confirm".

## 17. Reset of ModBus fans

If a fan is accidentally programmed to the wrong address (e.g., supply instead of exhaust), it can be reset to its default settings when delivered.

**NOTE:** To reset the fan, higher authorization is required. Level 4: OEM, password. This can be obtained in consultation with Flexit's service organization.

Start by disconnecting the other fan to identify its identity (address). It should display "OK" on one of the statuses below and "Alarm" on the other.



**Start page > Main menu > Configuration > Configuration IOs > Integrations > SupplyFan Modbus > ExhFan Modbus**

If "OK" is displayed on the Supply Fan, then the fan is configured as a supply fan. If "OK" is displayed on the Exhaust Fan, then the fan is configured as an exhaust fan.

To reset the fan, go to Factory Reset and select the relevant fan, the one with the "OK" status.



**Start page > Main menu > Configuration > Configuration IOs > Integrations > Factory Reset > Supply 1 > Extract 1**

## 18. Zero-point calibration of pressure sensors

If the pressure sensors for fans and filters display incorrect readings (they should show 0Pa when the fans are idle, the doors are open, and the outdoor/exhaust dampers are closed), they can be calibrated.

To check their readings, stop the unit by setting the Service switch to OFF.

1. Ensure that the "SERVICE SWITCH" is set to "OFF".



**Start page > SERVICE SWITCH > Off**

2. Push "Confirm".
3. Wait until the fans have stopped (may take up to 180 seconds for cooling down) before opening the doors. If outdoor and exhaust dampers are installed, ensure that they are closed.
4. Then, proceed to the following path. **NOTE:** Level 4: OEM, password. This can be obtained in consultation with Flexit's service organization.



**Start page > Main menu > Configuration > Configuration IOs > Integrations > Comm. info MB-Extender**

5. All the following values should be 0 when the unit is idle:
  - Filter pressure 1 = Supply air filter
  - Filter pressure 2 = Exhaust air filter
  - Airflow 1 = Supply air fan
  - Airflow 2 = Exhaust air fan

6. To reset, go to:



**Start page > Main menu > Configuration > Configuration IOs > Integrations > Comm.info MB-Extender > Set DeviceMode = Idle Mode**

7. And then proceed to the following to calibrate the sensors.



**Start page > Main menu > Configuration > Configuration IOs > Integrations > Comm.info MB-Extender > Zero Point Cal. Pressur = Yes**

8. After that, you must switch back to Online mode.



**Start page > Main menu > Configuration > Configuration IOs > Integrations > Comm.info MB-Extender > Set DeviceMode = OnLine Mode**

## 19. Emergency Stop

The unit can be stopped via an external emergency stop.

1. To activate the function, go through the following path and enable the feature.

**Start page > Main menu > Configuration > Configuration 1 > Emergency stop = Yes**

2. Afterward, restart the controller.

**Start page > Main menu > Configuration > Configuration 1 > Restart**



3. Set which input the function should be connected to.

**Start page > Main menu > Configuration > Configuration IOs > Digital inputs > Emergency stop**

4. Set this to D4. If this one is not available, you can use an input connected to another function, such as Digital Speed Input 3 (DI3) located at P12-34. To use P12-34, the function DI3 must be removed from this input. This is done as follows:

**Start page > Main menu > Configuration > Configuration 1 > Ext control input = 2**

5. Afterwards, restart the controller.


**Start page > Main menu > Configuration > Configuration 1 > Restart**



6. To change the contact function between NO/NC.

**Start page > Main menu > Unit > Inputs > Digital inputs > Emergency stop > Contact function**

7. The emergency stop signal should be potential-free and connected between P12-32 and P12-35 if D4 is selected previously. If D1 is selected, it should be connected between P12-28 and P12-34 as follows.



| Block no. | Function            |
|-----------|---------------------|
| Alt 1     |                     |
| 32        | 24V (REF)           |
| 35        | Emergency stop (DI) |
| Alt 2     |                     |
| 28        | G0 (REF)            |
| 34        | Emergency stop (DI) |

## 20. Electrical battery

Follow manual 118206 to see how the electric battery should be installed.

To set up the automation.



**Start page > Quick menu > Commissioning > Config.After heater > Type of Heater = Electrical**

If the electrical battery has two stages (refer to the battery manual), activate the second stage here:



**Start page > Main menu > Configuration > Configuration 2 > El heating 2 = Yes**

After making the change, a restart should be performed.



**Start page > Quick menu > Commissioning > Config.After heater > Restart = Execute**



**RESTART**

## 21. Water battery

Follow manual 118205 to see how the water battery should be installed.

To set up the automation.



**Start page > Quick menu > Commissioning > Config.After heater > Type of Heater = Water**

After making the change, a restart should be performed.



**Start page > Quick menu > Commissioning > Config.After heater > Restart = Execute**



**RESTART**

## 22. Test of functions

When all accessories are connected and the unit is ready for commissioning, you can enter a menu to test, for example, pumps, valves, dampers, etc., individually before starting up the unit.

Place the unit in service stop mode.



**Start page > SERVICE SWITCH > Off**

Then proceed to:



**Start page > Quick menu > Commissioning > Output test**

Depending on the configuration (e.g., electric/water battery), the unconfigured accessories are displayed according to the list below.

| Digital outputs    |     |
|--------------------|-----|
| Pump heating       | Off |
| Pump cooling       | Off |
| Outdoor air damper | Off |
| Exhaust air damper | Off |
| Analog outputs     |     |
| Supply air fan     | 0%  |
| Extract air fan    | 0%  |
| Heat recovery      | 0%  |
| Heating            | 0%  |
| Cooling            | 0%  |

To test an output, navigate to the relevant function:

For Digital Output: Manual control, switch between Auto and On.

On = the output is controlled manually.

Auto = the output is controlled by the automation system.

For Analog Output: Manual control, set 0-100% to provide a signal to the output.

0% = 0V

100% = 10V

When one or more outputs are operated manually, the status lamp on the HMI display alternates between yellow and green.

**NOTE! Reset all outputs to Auto after the test is completed.**

## 23. Expansion module SP90

The SP90 is an expansion module that can be connected to a CS2500 controller.

The expansion module offers the following possibilities:

- Power supply: 24 VAC or 24 VDC directly from the controller
- 8 universal I/O (configurable inputs/outputs, for analog or digital signals)
- 4 relay outputs (NO contact)
- 2 analog outputs (0...10 VDC)

Follow manual 118265 for instructions on how to connect the module to the controller.

I/O list of the I/O module.

| Step |    | Function  |
|------|----|---|
| Q13  | DO | Fire fan  |
| Q14  | DO | Fire fan  |
| Q23  | DO | Spare   |
| Q24  | DO | Spare   |
| Q33  | DO | Additional cooling, pump                        |
| Q34  | DO | Additional cooling, pump                        |
| Q43  | DO | Additional water/Electrical heating             |
| Q44  | DO | Additional water/Electrical heating             |
| Y1   | AO | Mixing damper (0-10 V)                          |
| M    | -  | G0  |
| Y2   | AO | Additional cooling (0-10 V)                     |
| X1   | AI | External temperature setpoint (0-10 V)          |
| M    | -  | G0  |
| X2   | AI | Temperature, exhaust air                        |
| X3   | AI | Temperature frost guard, additional heating     |
| M    | -  | G0  |
| X4   | AI | Temperature, exhaust air by additional sequence |
| X5   | AO | Additional heating (0-10 V)                     |
| M    | -  | G0  |
| X6   | DI | Alarm, additional electrical heating            |
| X7   | -  | Spare   |
| M    | -  | G0  |
| X8   | -  | Spare   |

## 24. Additional cooling

The default function of the main regulator is to control one heating/cooling step. The SP90 module can control additional steps, either in sequence or as a standalone temperature zone.

An additional cooling coil can be connected to the system. It can be included in the temperature regulation loop in two different ways, either as a separate temperature zone (standalone) or as part of the ordinary sequence.

To activate the function:

 **Start page > Main menu > Configuration > Configuration 1 > Additional cooling**

| Parameter         | Function  |
|-------------------|---|
| Water             | Analog output for liquid battery                              |
| Cooling machine 1 | One digital output for cooling machine                        |
| Cooling machine 2 | Two digital outputs for cooling machine, sequence regulation. |
| Cooling machine 3 | Two digital outputs for cooling, binary regulation.           |
| ModBus            | Modbus-controlled valve in combination with liquid battery    |

After making a change in a configuration menu, a restart is required.


 **Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



To configure the function:


 **Start page > Main menu > Configuration > Configuration 2 > Cooling 2 control**

| Parameter  | Function   |
|------------|--|
| Sequence   | Additional cooling is included in the cooling sequence after the ordinary cooling steps DX1-DX3  |
| Standalone | Additional cooling is regulated separately independently of the ordinary temperature regulation.<br><b>NB!</b> This function requires installation of an additional supply air sensor. |



| Block no. | Function                                 |
|-----------|--|
| Q33       | Q33 Additional cooling/Cooling machine 1 |
| Q34       | Q34 Additional cooling/Cooling machine 1 |
| Q43       | Q43 Additional cooling/Cooling machine 2 |
| Q44       | Q44 Additional cooling/Cooling machine 2 |
| X4        | Supply air sensor, Additional cooling    |
| M         | Supply air sensor, Additional cooling    |
| Y2        | Additional cooling 0-10V                 |
| M         | Additional cooling G0                    |

After making a change in a configuration menu, a restart is required.

 **Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



After a restart, outputs to the cooling machine must be selected.

 **Start page > Main menu > Configuration > Config.Inputs/Outputs > Outputs tmp control**

Additional cooling 1 = 1Q3  
Additional cooling 2 = 1Q4

If 'Standalone' is selected, the setpoint for Additional cooling is adjusted via:

**Start page > Quick menu > Setpoints/ Settings**

| Parameter                | Function   |
|--------------------------|--|
| Setpoint additional seq. | Indicates the supply air temperature for Additional cooling in 'Standalone' mode |

For other cooling settings, see chap. 6.

## 25. Additional heating

An additional heating coil can be connected to the system. It can be included in the temperature regulation in two different ways, either as a separate temperature zone (standalone) or as an additional coil as part of the ordinary sequence.

### 25.1. For water heating

To activate the function:

**Start page > Main menu > Configuration > Configuration 1 > Additional heating**

| Parameter                       | Function   |
|---------------------------------|--|
| Yes                             | Additional liquid heating activated  |
| Yes+Preh. Outdoor temp.         | Additional liquid heating activated as preheating and controlled by the outdoor temperature      |
| Yes+Preh.Frost protection temp. | Additional liquid heating activated as preheating and controlled by the frost temperature sensor |
| ModBus                          | Modbus-controlled valve in combination with liquid battery                                       |

After making a change in a configuration menu, a restart is required.

**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



#### 25.1.1. For configuration of water heating

**Start page > Main menu > Configuration > Configuration 2 > Frost protection, additional heating**


| Parameter   | Function   |
|-------------|--|
| No          | No frost protection                                  |
| Sensor      | Frost protection via sensor                          |
| Sensor+2 sp | Frost protection via sensor and two setpoints        |
| Guard       | Frost protection via guard                           |
| Sens+Guard  | Frost protection via sensor and guard                |
| 2sp+Guard   | Frost protection via sensor, two setpoints and guard |

### 25.1.2. For configuration of circulation pump for water heating



**Start page > Main menu > Configuration > Configuration 2 > Pump, additional heating**

| Parameter  | Function                                       |
|------------|--|
| No         | No circulation pump activated                  |
| Yes        | Circulation pump without maintenance operation |
| Yes+Motion | Circulation pump with maintenance operation    |



| Block no. | Function                              |
|-----------|---------------------------------------|
| X3        | Frost protection sensor               |
| M         | Frost protection sensor               |
| X4        | Supply air sensor, additional heating |
| M         | Supply air sensor, additional heating |
| X6        | Frost guard                           |
| M         | Frost guard                           |
| Q43       | Pump output, additional heating       |
| Q44       | Pump output, additional heating       |
| X5        | Additional heating 0-10V              |
| M         | Additional heating G0                 |



**Start page > Main menu > Configuration > Configuration 2 > Additional heating regulation**

| Parameter                        | Function   |
|----------------------------------|--|
| Standalone                       | Additional heating is regulated separately independently of the ordinary temperature regulation<br><b>NB!</b> This function requires installation of an additional supply air sensor |
| Seq.: Heating-Additional heating | Additional heating is included in the heating sequence AFTER the ordinary heating step   |
| Seq.: Additional heating-Heating | Additional heating is included in the heating sequence BEFORE the ordinary heating step  |

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 2 > Restart > Execute**



RESTART

### 25.1.3. For parameter setting of the water heating



**Start page > Main menu > Unit > Temperature regulation > Additional heating**

| Parameter                | Function  |
|--------------------------|---|
| Regulator                | Current heating regulator value                                   |
| Output signal            | Current value at analogue output                                  |
| Setpoint additional seq. | Setpoint for additional sequence when Standalone mode is selected |
| Frost protection         | Current frost regulator value                                     |
| Pump                     | Current pump status   |
| Preheating               | Current preheating mode   |
| Frost guard              | Current position of frost guard                                   |

If "Standalone" is selected, the setpoint for Additional water heating is adjusted via:



**Start page > Quick menu > Setpoints/ Settings**

| Parameter                | Function   |
|--------------------------|--|
| Setpoint additional seq. | Indicates the supply air temperature for Additional water heating in 'Standalone' mode |



## 25.2. For electrical heating

To activate the function:



**Start page > Main menu > Configuration > Configuration 1 > Additional electric heating**

| Parameter | Function  |
|-----------|---|
| No        | No additional electric heating coil activated             |
| Analogue  | Additional heating coil with analogue control activated   |
| 1step     | Additional one-step electric heating register activated   |
| 2step     | Additional two-step electric heating register activated   |
| 3stepBin  | Additional three-step electric heating register activated |

After restarting, the outputs to the electrical stages must be selected.



**Start page > Main menu > Configuration > Config.Inputs/Outputs > Outputs tmp control**

Additional heating 1 = 1Q3  
 Additional heating 2 = 1Q4

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**




### 25.2.1. For configuration of electric heating



**Start page > Main menu > Configuration > Configuration 2 > Alarm, additional electric heating**

| Parameter | Function                 |
|-----------|--------------------------|
| No        | No alarm input activated |
| Yes       | Alarm input activated    |



| Block no. | Function                             |
|-----------|--------------------------------------|
| X5        | Alarm input electrical heating 0-10V |
| M         | Alarm input electrical heating G0    |
| X6        | Fire thermostat DI                   |
| M         | Fire thermostat DI                   |
| Q23       | Electrical heating input 1 DO        |
| Q24       | Electrical heating input 1 DO        |
| Q43       | Electrical heating input 2 DO        |
| Q44       | Electrical heating input 2 DO        |



**Start page > Main menu > Configuration > Configuration 2 > Additional electric heating regulator**

| Parameter                        | Function   |
|----------------------------------|--|
| Standalone                       | Additional heating is regulated separately independently of the ordinary temperature regulation<br><b>NB! This function requires installation of an additional supply air sensor</b> |
| Seq.: Heating-Additional heating | Additional heating is included in the heating sequence AFTER the ordinary heating step   |
| Seq.: Additional heating-Heating | Additional heating is included in the heating sequence BEFORE the ordinary heating step  |

After making a change in a configuration menu, a restart is required.

 **Start page > Main menu > Configuration > Configuration 2 > Restart > Execute**

 **RESTART**

### 25.2.2. For parameter setting of the additional heating

 **Start page > Main menu > Unit > Temperature regulation > Additional electric heating**

| Parameter                | Function   |
|--------------------------|--|
| Regulator                | Current heating regulator value  |
| Output signal            | Current value at analogue output                                       |
| Operation                | Current position of electric heating register                          |
| Setpoint additional seq. | Setpoint for additional sequence when Standalone mode is selected      |
| Alarm                    | Alarm mode for additional heating                                      |
| Start step 1             | Heating regulator value in % for start of first step                   |
| Start step 2             | Heating regulator value in % for start of second step                  |
| Start step 3             | Heating regulator value in % for start of third step                   |
| Hysteresis, power down   | Power down hysteresis in % of steps                                    |
| Max.signal fan st.       | Limits the maximum heating requirement in % at the different fan steps |

**> Example of start step and power down hysteresis and limitation of heating requirement at different fan steps**

|   |                    |
|---|--------------------|
| Start step 1 = 20%  | Start step 2 = 40% |
| Fan step 1 = 30%  | Fan step 2 = 60%   |
| Power down hysteresis = 10%   |                    |
| Heating step 1 switches in at 20% heating requirement and remains at max. 30% force while the fan is on step 1. Switches off when the heating requirement has fallen to 10%.                                |                    |
| Heating step 2 switches in at 40% heating requirement and remains at max. 60% force while the fan is on step 2. Switches off when the heating requirement has fallen to 30% or the fan goes down to step 1. |                    |

If "Standalone" is selected, the setpoint for Additional electrical heating is adjusted via:

 **Start page > Quick menu > Setpoints/Settings**

| Parameter                | Function   |
|--------------------------|--|
| Setpoint additional seq. | Indicates the supply air temperature for Additional water heating in 'Standalone' mode |

## 26. Fire fan

The unit has a potential-free output to control an external fire fan. This function is activated via the fire/smoke input. This assumes that the fire alarm function is activated in the automatic control system (see main manual).

Configure as follows:



**Start page > Main menu > Configuration > Configuration 1 > Fire fan**

| Parameter | Function             |
|-----------|----------------------|
| Yes       | Function activated   |
| No        | Function deactivated |

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



After the restart, the unit starts with an alarm: 'No config. IO' This means that an output must be defined for the fire fan function.

This is done via:



**Start page > Main menu > Configuration > Config.Inputs/Outputs > Outputs, Fans > Fire fan Select**


| Parameter | Function  |
|-----------|---|
| Q11       | Selected unless the operating mode indication function is activated |
| Q12       | Selected unless the <b>DX step</b> 2/3 function is activated        |

To switch contact function for the output:



**Start page > Main menu > Unit > Outputs > Fire fan > Contact function**

| Parameter | Function               |
|-----------|------------------------|
| NO        | Output normally open   |
| NC        | Output normally closed |




| Selection | Block no. | Function        |
|-----------|-----------|-----------------|
| Q11       | Q13       | Fire fan output |
|           | Q14       | Fire fan output |
| Q12       | Q23       | Fire fan output |
|           | Q24       | Fire fan output |

## 27. External setpoint

The temperature setpoint can be controlled externally. It is possible to specify whether the external setpoint is to be used as setpoint compensation or an absolute value. The value corresponds to the comfort setpoint.

**Start page > Main menu > Configuration > Configuration 1 > External setpoint**

| Parameter | Function   |
|-----------|--|
| No        | External setpoint deactivated                            |
| Volt      | External setpoint activated and regulated via 0-10 V     |
| Ohm       | External setpoint activated and regulated via 0-2.5 kOhm |
| QAA27     | Not used   |
| BSG21     | Not used   |



| Plint nr. | Funktion                 |
|-----------|--------------------------|
| X1        | External setpoint signal |
| M         | External setpoint G0     |

After making a change in a configuration menu, a restart is required.

**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



### 27.1. For configuration of external setpoint

**Start page > Main menu > Configuration > Configuration 2 > Ext. setp. function**

| Parameter | Function              |
|-----------|-----------------------|
| Comp.     | Setpoint compensation |
| Main      | Main setpoint         |

#### > Example of setpoint compensation

The comfort setpoint is set to +20 degrees

Ext. setpoint curve Y1 = -5

Ext. setpoint curve Y2 = +5

0 V at the input produces a setpoint of +15 degrees

10 V at the input produces a setpoint of +25 degrees

#### > Example of main setpoint

Ext. setpoint curve Y1 = +10

Ext. setpoint curve Y2 = +30

0 V at the input produces a setpoint of +10 degrees

10 V at the input produces a setpoint of +30 degrees

The comfort setpoint in the regulator has no function

After making a change in a configuration menu, a restart is required.

**Start page > Main menu > Configuration > Configuration 2 > Restart > Execute**



### 27.2. For parameter setting of external setpoint


**Start page > Quick menu > Setup > Setpoints/Settings > All settings > External setpoint**

| Parameter              | Function                                |
|------------------------|---|
| Ext. setpoint curve Y1 | Indicates the lowest external setpoint  |
| Ext. setpoint curve Y2 | Indicates the highest external setpoint |

## 28. Mixing damper

Mixing dampers can be installed to enable the recirculation of exhaust air back into the supply air duct. This can be done with up to 80% recirculation and 20% outdoor air. Below is a simplified overview of the components involved.


To be smoothly regulated between open and closed positions, all the dampers must have a 0-10V control.




To activate the function:

**Start page > Main menu > Configuration > Configuration 1 > Hrec damper**

| Parameter      | Function  |
|----------------|---|
| Normal         | Mixing damper activated, output signal 100% for full circulation    |
| Inverted       | Mixing damper activated, output signal 0% for full circulation      |
| MB Exhaust air | Not used  |
| MB Outside air | Not used  |
| MB Mix air     | Not used  |
| Limit Extr.fan | The exhaust fan is controlled by the position of the mixing damper. |



| Block no. | Function                          |
|-----------|-----------------------------------|
| Y1        | Damper output 0-10V Mixing damper |
| M         | Damper output G0 Mixing damper    |
| P12-32    | +24V power supply Mixing damper   |



After making a change in a configuration menu, a restart is required.

**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



### 28.1. For configuration of the heating sequence



**Start page > Main menu > Configuration > Configuration 2 > Mixing damper sequence**

| Parameter      | Function  |
|----------------|---|
| Damper-Heating | Mixing damper primary, heating register (recovery system+heating) secondary |
| Heating-Damper | Heating register (recovery system+heating) primary, mixing damper secondary |

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 2 > Restart > Execute**



### 28.2. For parameter setting



**Start page > Main menu > Unit > Temperature regulation > Mixing damper**

| Parameter        | Function  |
|------------------|---|
| Regulator        | Current regulator value for mixed air   |
| Output signal    | Current value for damper actuator   |
| Recovery         | Shows current heat recovery. For Mixing damper = Normal, this value is always the same as the output signal. For Mixing damper = Inverted, this value is always the inverted output signal. |
| Min. outdoor air | The minimum volume of outdoor air. The regulator output signal is limited to 100% - Min. outdoor air. This ensures that a certain volume of outdoor air is always blown into the room       |
| Start time       | Time for the regulator's start process (100% recirculation).  |
| Start temp.      | Temperature limit for start process   |

#### > Example of mixing damper

At the start, the mixing damper is entirely open during the period for Start time if outdoor air temperature < Start temp. The regulator determines the current position after this period. If heating is required at the start, the heating register is activated in parallel and after start has been completed the mixed air regulator for heat recovery is set to max. (100% - Min. outdoor air).

### 29. Exhaust air sensor

A temperature sensor can be installed in the exhaust air for temperature measurement. To activate the function:



**Start page > Main menu > Configuration > Configuration 1 > Exhaust air = Yes**

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 1 > Restart > Execute**



After the sensor is configured, it should be connected to a physical input.



**Start page > Main menu > Configuration > Config.IOs > Temperatures > Exhaust air/ Pos = 1X2**

### 30. Efficiency measurement

Once the exhaust air sensor is installed, the efficiency of the heat exchanger can be read out. **NB!** This is not an exact value of the efficiency as there are many factors involved such as humidity, balance between supply air/exhaust air, etc.



**Start page > Main menu > Configuration > Configuration 2 > Hrecefficiency = Exhaust air**

After making a change in a configuration menu, a restart is required.



**Start page > Main menu > Configuration > Configuration 2 > Restart > Execute**



Current efficiency is displayed under:

**Start page > Main overview**





Flexit AS, Moseveien 8, N-1870 Ørje  
[www.flexit.com](http://www.flexit.com)